




Job No.

Checking, replacing and torquing conrod bolts . . . . .	03 – 310
Reconditioning and checking angles on bearing bores . . . . .	03-313
Removal and installation of pistons . . . . .	-316
Checking and reconditioning crankshaft . . . . .	-318
Installation of crankshaft bearings . . . . .	- 320
Replacing front crankshaft radial seal . . . . .	- 324
Replacing rear crankshaft radial seal . . . . .	- 327
Removal and installation of grooved ball bearing in crankshaft . . . . .	- 330
Removal and installation of vibration damper . . . . .	- 342
Checking and correcting setting of TDC pulse generator . . . . .	- 345
Removal and installation of crankshaft gear . . . . .	- 350
Removal and installation of flywheel or flex plate . . . . .	-410
Remachining flywheel . . . . .	- 420
Replacing ring gear on flywheel . . . . .	- 430

## 03-310 Checking, replacing and torquing conrod bolts



P03-0146-13

- Conrod bolts ..... before reuse, measure the smallest bolt shaft dia. If the dia. reaches or is less than the minimum shaft dia. of 7.1 mm, replace the conrod bolt.
- Thread and bolt head contact surface . . . . . oil before installing.
- Conrod bolt initial and angle of rotation torque ..... initial torque 30 Nm.  
 Angle of rotation torque 90 – 1 00°, use special tool 001 589 66 21 00.  
 Pay **attention** to note.


### Dimensions of conrod bolts

Part No.	Thread dia.	Stretch shaft dia. when new	Minimum stretch shaft dia. "c"
102 038 00 71	M9 x 1	7.4 – 0.1	7.1

### Torque of conrod bolt



Initial tightening torque	30 Nm
Angle of rotation torque	90° – 100°

## Special tool



### Note

In September 1988 conrod bolts with a longer thread were installed.  
These conrod bolts are not supplied as replacement parts.




A 1st version  
B 2nd version


Standard **implementation: 09/86**

Model	Engine	Engine End No.	
		Manual transmission	Automatic transmission
201.028	102.985	027063 - 028449	076715 - 077418

If no torque wrench is available, the conrod bolt can be tightened according to the specified torquing angle with a socket wrench in a single operation. To prevent any angular errors, do not use a bending rod torque wrench for tightening according to angle degrees.




## 03-313 Reconditioning and checking angles of bearing bores



Conrod bolt (28) .....	check (03-310).
Conrod bearing cover (26) .....	install without bearing shells (31 and 31a), oil thread and bolt head contact surface, 30 Nm.
Basic bore .....	measure; if the value of 51.619 mm is exceeded, or if it is conical, dress bearing cover up to max. 0.02 mm (step 3).
Conrod bushing (27) .....	press in, pay attention to oil holes. Insertion pressure approx. 2500 N. Hollow out conrod bushing by turning or reaming. Dress side contact surfaces on dressing plate (steps 4 to 6).

Conrod (25) .....	check angles of bearing bores with conrod tester. Align conrod bearing bore to small end bushing bore (steps 7 and 8).
Axial twist .....	to small end bushing bore, check (step 9).

**Special tool**



**Commercial tool**

---

Conrod aligning tool	e. g. Hahn & Kolb D-7000 Stuttgart Model BC 503
----------------------	---

---


**Data**

Centre of conrod bearing bore to center of small end bushing bore (L, Fig. para 4)	144 95 145.05
Width of conrod at conrod bearing bore and at small end bushing bore (B, Fig. para 4)	22 000 21.948
Basic bore for conrod bearing shells	51 600 51.619
Basic bore for small end bushing (D1, Fig. para 4)	24 521 24.500
Small end bushing OD	24 590 24.550
Small end bushing ID (D2, Fig. para 4)	22.007 22.013
Peak-to-valley height of small end bushing on inside	0.005
Permissible axial twist of conrod bearing bore to small end bushing bore related to 100 mm length	0.1
Permissible variation of axial parallelism: conrod bearing bore to small end bushing bore related to 100 mm length	<b>0.045</b>
Permissible variation of conrod bearing bore from roughness	0.02
Permissible difference in weight of complete conrod within an engine	5 grams



**Note**


The end play of the conrod is limited not at the crankshaft journals but at the piston pin bosses (piston-guided conrod, arrows).



Conrods which have been overheated as a result of a bearing damage (blue discolouration), must not be reused.

Conrod and conrod bearing cover are marked together. The conrod shaft must not show any cross scoring and notches.

Conrods are supplied as replacement parts with a machined small end bushing.



To reduce the distortion tendency, conrods with a modified material were installed from June through September 1985 and are installed effective February 1987.

**Standard implementation: June through September 1985**


Model	Engine	Engine End No.		Vehicle Ident End No.	
		Manual transmission	Automatic transmission	A	F
<b>201.024</b>	102.961	-	056261 - 056430		124773 - 135776
<b>201.024</b> (USA)	102.985	002118 - 002665	018026 - 023402	-	120052 - 153013

\* not covered

Effective 09/89 all conrods are subject to additional heat treatment to prevent conrod distortion resulting in noises when the engine is operating at normal temperature.

### **Reconditioning**


- 1 Check conrod bolts, replace if necessary (03-310).
- 2 Install conrod bearing cover. To perform the step, oil thread and bolt head contact surface and tighten to 30 + 5 Nm.
- 3 Measure conrod bearing basic bore. If the basic bore exceeds the value of 51.619 mm or is conical, dress contact face of bearing cover on a surface plate to max. 0.02 mm.



4 Press in new small end bushing so that the oil bores are aligned (arrow).  
Press-fitting pressure 2500 N.

5 Hollow out small end bushing by turning or reaming.


6 Dress side contact faces of conrod on the surface plate.




### Checking angles

7 Check angles of bearing bores with a conrod tester.

8 Align conrod bearing bore to small end bushing bore (parallelism).



9 Check axial twist of conrod bearing bore relative to small end bushing bore and correct, if necessary.




## 03-316 Removal and installation of pistons

Preceding work:

Removal of engine (01-030).

Removal of cylinder head (01-415).

Removal of oil pan (01-310).






- |  |   |
|--|---|
| Conrod bearing cover (26) .....          | unbolt, bolt on, 30 Nm and 90° angle of rotation torque. Do not mix up top and bottom bearing shells. Pay attention to matching of <b>conrod</b> and bearing cap (step 12). |
| Conrod bolt (28) .....                   | check (03-310).   |
| Piston (32) and <b>conrod</b> (25) ..... | push out of crankcase upwards.  |
| Locking ring (37) .....                  | remove (step 3) and insert (step 9).  |
| Piston pin (36) .....                    | press out and press in by hand (step 8).  |

### Installation Instruction

Insert **conrod** into piston so that the chamfered splash bore in the small end bearing with the arrow in the piston crown are pointing in direction of travel; **do not** heat piston.

- Piston (32) ..... . . . . . check condition, pay attention to installation position.
- Piston rings (33, 34 and 35) .. . . . check condition, pay attention to installation position, "Top" must face upwards. Position ring gaps evenly around circumference of piston.
- Piston (32) with conrod (25) ... .. install with tensioning strap 000 589 04 14 00, oil piston beforehand and clean cylinder bores (steps 10 and 11).
- Piston projection ..... . . . . . check in TDC position (step 14).

**Special tools**



**Matching pistons and cylinders**

Engine	Group No.	Piston dia.	Cylinder dia.	Group code letter	Piston dia.	Cylinder dia.
102.922/924 102.962963 Standard (normal size)	0	<u>88.968</u> 88.982	<u>88.998</u> 89.008	A	<u>88.973</u> 88.979	<u>89.000</u> 89.006
	1	<u>88.978</u> 88.992	<u>89.009</u> 89.018	X	<u>88.978</u> 88.986	<u>89.007</u> 89.012
	2	<u>88.988</u> 89.002	<u>89.019</u> 89.028	B	<u>88.985</u> 88.991	<u>89.013</u> 89.018
Repair size 1 (+0.5)	0	<u>89.468</u> 89.482	<u>89.498</u> 89.508	A	<u>89.473</u> 89.479	<u>89.500</u> 89.506
	1	89.478 89.492	<u>89.509</u> <u>89.518</u>	X	<u>89.478</u> 89.486	<u>89.507</u> 89.512
	2	<u>89.488</u> 89.502	89.519 89.528	B	<u>89.485</u> 89.491	<u>89.513</u> 89.518

Engine	Group No.	Piston dia.	Cylinder dia.	Group code letter	Piston dia.	Cylinder dia.
Repair size 2 (+ 1.0)	0	<u>89.968</u> 89.982	<u>89.998</u> 90.008	A	<u>89.973</u> 89.979	<u>90.000</u> 90.006
	1	<u>89.978</u> 89.992	<u>90.009</u> 90.018	X	<u>89.978</u> 89.986	<u>90.007</u> 90.012
	2	<u>89.988</u> 90.002	<u>90.019</u> 90.028	B	<u>89.985</u> 89.991	<u>90.013</u> 90.018
102.982/985 Standard (normal size)	0	<u>95.469</u> 95.481	<u>95.498</u> 95.508	A	<u>95.473</u> 95.479	<u>95.500</u> 95.506
	1	<u>95.479</u> 95.491	<u>95.509</u> 95.518	X	<u>95.478</u> 95.486	<u>95.507</u> 95.512
	2	<u>95.489</u> 95.501	<u>95.519</u> 95.528	B	<u>95.485</u> 95.491	<u>95.513</u> 95.518
Repair size 1 (+ 0.5)	0	<u>95.969</u> 95.981	<u>95.998</u> 96.008	A	<u>95.973</u> 95.979	<u>96.000</u> 96.006
	1	<u>95.979</u> 95.991	<u>96.018</u> 96.009	X	<u>95.978</u> 95.986	<u>96.007</u> 96.012
	2	<u>95.989</u> 96.001	<u>96.019</u> 96.028	B	<u>95.985</u> 95.991	<u>96.013</u> 96.018
Repair size 2 (+ 1.0)	0	<u>96.469</u> 96.481	<u>96.498</u> 96.508	A	<u>96.473</u> 96.479	<u>96.500</u> 96.506
	1	<u>96.479</u> 96.491	<u>96.509</u> 96.518	X	<u>95.478</u> 96.486	<u>96.507</u> 96.512
	2	<u>96.489</u> 96.501	<u>96.519</u> 96.528	B	<u>96.485</u> 96.491	<u>96.513</u> 96.518


## Test data

		When new	Wear limit
Piston play	with Group No. 0, 1 or 2	0.016 – 0.040	–
	with Group code letter A, X or B	0.020 – 0.034	–
Difference in weight of pistons in an engine			10 g
Piston pin dia.		21.995 – 22.000	–
Piston pin play	in small end bush	0.007 – 0.018	–
	in piston	0.002 – 0.012	–
End gap of piston rings	groove 1	0.30 – 0.55	1.0
	groove 2	0.30 – 0.55	0.8
	groove 3	0.25 – 0.50	0.8
Vertical play of piston rings	groove 1	0.050 – 0.085	0.15
	groove 2	0.010 – 0.030	0.1
	groove 3	0.010 – 0.045	0.1
Conrod in piston (end play)		0.050 – 0.450	–
Piston projection		0.60 – 1.0	–

## Note

The pistons and cylinder bores are arranged into three diameter groups within the tolerance and were previously identified with the figures 0, 1 and 2.

As of April 1988 the tolerance stages are identified with the Group code letters A, X and B. The identification is given as before in the mating face of the crankcase and in the piston crown.



previously	now
0	A
1	X
2	B

---

Only pistons with the Group code letter "X" are supplied for repair purposes. These pistons should also be installed in the cylinder bores with the Group code letters "A" or "B".

Only pistons with Group code letters are also supplied for the previous engines with Group numbers 0, 1 and 2, namely piston "X" for Group No. 0 and 1. Piston "B" for Group No. 2. When performing repairs, the cylinder bores should be honed according to the dimensions of the existing pistons plus piston play.


The piston crown is designed differently in the individual engines. The piston crown of normal compression engines is either smooth or provided with a recess. In addition, there are two valve niches each in the piston crown.




**Caution!**

A recess with a diameter of 50 mm appears on the piston crown of pistons in repair size version.

Piston crown smooth, two valve niches



P03-0010-13




Engine 102.985

P03-0011-13

Recess in piston crown, two valve niches  
D 70 mm dia.


T vanes according to piston  
(normal size, repair sizes)





P03-0012-13


All low compression engines have a step on the piston crown (except 102.985 **USA**, 1985 additionally one valve niche).

- 33 Rectangular ring with internal chamfer, running surface chrome-plated
- 34 Taper face oil scraper ring, running surface precision-turned
- 35 Chamfered oil control ring with garter spring, running surfaces chrome-plated
- T Height of size 2.0 mm



P03-0013-13



Engine 102.985 

As the design of the piston crown (flat, recess or step) has an influence on the compression, the pistons are not interchangeable. Two repair sizes (each step + 0.5 mm dia.) are approved for the pistons of all engines.

The shape of the piston and the roughness of the grinding pattern of the pistons has been modified from 0.8 mm to 1.2 mm on Engine 102.982 as a noise-reducing measure.

On engine 102.985 (USA) the rectangular ring manufactured by Götze is installed in groove I of the piston manufactured by Mahle and KS. The running surface of this piston ring is chrome-plated, asymmetrically crowned and sharp-edged at the bottom to reduce oil consumption.

**Standard Implementation: 03/88 (Mahle)**


Model	Engine	Engine End No.		Vehicle Ident End No.	
		Manual transmission	Automatic transmission	A	F
201. 028 (USA)	1102. 985	023341	069631		484718

**Standard Implementation:03/88 (KS)**


Model	Engine	Engine End No.		Vehicle Ident End No.	
		Manual transmission	Automatic transmission	A	F
201. 028 (USA)	102. 985	023788	070989		492527

The Group code numbers on the pistons and on the mating face of the crankcase have been replaced by Group code letters. As a result, the cylinder diameters and matching of pistons and cylinders have also been modified (refer to data).

Crankcase with Group numbers




Crankcase with Group code letters



## Removal and installation


1 Unbolt conrod bearing cover and remove conrod together with piston upwards.

2 Check conrod bolts (03310).



3 Remove piston pin locking element with screwdriver and press out piston pin.

4 Recondition conrod and check angles of bearing bores, if necessary (03-313).




5 If the pistons are worn, check the gap clearance and end play of the piston rings (refer to table). Check that the piston rings move easily. Pay attention to installation position: "Top" must be facing upwards. Distribute the ring gaps evenly around the circumference of the piston.

6 Oil piston pin and small end bushes.


7 Install piston so that the chamfered splash bore in the small end bearing (arrow) and the arrow in the piston crown are facing in direction of travel.

### Caution!


Do not heat piston.



8 Press in piston pin by hand.




9 Insert piston pin locking element into the groove.




10 Oil cleaned cylinder bores, conrod bearing journals, conrod bearing shells and pistons.

11 Install tensioning strap for piston rings and install piston into cylinder bore with arrow facing in direction of travel.




12 Mount conrod bearing cover onto the conrod with the code marks (arrows) aligned with each other and torque conrod bolts to an initial torque of 30 Nm and angle of rotation torque of 90°.


13 Turn crankshaft and check clearance between piston pin boss and conrod.



14 Measure the distance between piston crown and crankcase mating face with the pistons in the TDC position (refer to table).



## 03-318 Checking and reconditioning crankshaft



### Data

Crankshaft normal size and repair sizes	Crankshaft journal dia.	Crankshaft journal width at thrust bearing	Crankpin dia.	Crankpin width
Normal size	<u>57.950</u> <u>57.965</u>	<u>28.500</u> <u>28.533</u>	<u>47.955</u> <u>47.965</u>	28.000 28.084
Normal size II	<u>57.935</u> <u>57.950</u>	or <u>28.600</u> <u>28.633</u>		
1st repair size	<u>57.705</u> <u>57.715</u>	<u>28.700</u> <u>28.721</u>	<u>47.705</u> <u>47.715</u>	up to 28.30
2nd repair size	<u>57.455</u> <u>57.465</u>	or <u>28.900</u> <u>28.921</u>	<u>47.455</u> <u>47.465</u>	
3rd repair size	<u>57.205</u> <u>57.215</u>	or <u>29.000</u> <u>29.021</u>	<u>47.205</u> <u>47.215</u>	
4th repair size	<u>56.955</u> <u>56.965</u>		<u>46.955</u> <u>46.965</u>	

Permissible out-of-roundness of crankshaft journals and crankpins		0.0025
Permissible conicity	crankpins	0.010
	crankshaft journals	0.010
Permissible axial runout of fit bearing		0.02
Fillet radii at the	crankshaft bearing journals	2.0 – 2.2
	crankpins	2.8 – 3.0
Bearing journals ground and fine-lapped, max peak-to-valley height $R_z$ (pm)		0.15
Crankshaft journal dia. front		29.987 – 30.000
Permissible variation of front crankshaft journal from concentricity <sup>1)2)</sup>		0.030
Running surface dia. for rear radial seal		92.874 – 92.928
Permissible variation of rear crankshaft flange	from concentricity <sup>1)</sup>	0.02
	from axial runout <sup>1)</sup>	0.012
Permissible variation of crankshaft journals from concentricity <sup>1)</sup>	journal II, IV	0.07
	journal III	0.10
Scleroscopic hardness of crankshaft journals and crankpins	when new	74 – 82
	limit value	60 <sup>3)</sup>
Permissible unbalance of crankshaft		14.5 cmg

<sup>1)</sup> When crankshaft mounted on outer crankshaft journals I and V and one full rotation.

<sup>2)</sup> If measurement performed when crankshaft installed, eliminate radial bearing play by pressing against crankshaft journal.


<sup>3)</sup> The limit value must exist at least at 2/3 of the circumference of the journal.

### Note

Maximum wear limit of crankshaft journals and crankpins 0.02 mm. The repair sizes listed in the table must be strictly adhered to. In addition, it is essential to adhere to the fillet radii at the crankshaft journals and crankpins when regrinding.



## Special tool



### Note


Adhere to the sequence of operations of the diagram below when checking and reconditioning crankshafts.


### Dianram

---


1) Refer to Section "Explanatory notes regarding diagram".

## A. Checking, grinding





## B. Hardening



## Explanatory notes regarding diagram

### **Crack test**

Clean crankshaft. The bearing journals must be free of oil and grease.

Magnetize crankshaft and apply fluorescent powder (flux).


A dye penetration method (immersing in bath or with spray can) may also be used.

Helpful tools: die, UV oil or fluorescent powder,  
cleaning agent,  
developer

### **Hardness test**

Test hardness with the drop hardness tester (scleroscopic hardness).


The minimum hardness of 60 must exist at 2/3 of the circumference of the journal.



### **Hardening**

The journals without hardened radii may be hardened inductively or with a flame. By contrast, the journals with hardened radii (arrows) must always be hardened inductively. If this is not possible, scrap crankshaft.

When hardening the journals without hardened radii, it is important to adhere to the distance A between hardening runout and radius (4 – 5 mm).



### **Inspection of hardening**

To achieve proper hardening, check the setting of the hardening system by metallographic ground surfaces.

These can be removed from test hardening operations on scrapped crankshafts.

Check hardening by etching the surface of the journal with a 2 % alcoholic nitric acid ( $HNO_3$ ).

No dark spots should appear on the surface of the journal.

Non-hardened radii change to a dark colour.

By contrast, the hardened radii must be just as bright as the surface of the journal.

As a comparison, it is recommended to perform etching on a metallographically tested journal.

Following this, carefully wash off the nitric acid with alcohol.

### **Corrosion protection**

Crankshafts which are not immediately re-installed, must be oiled with initial operation engine oil (SAE 30).

## 03-320 Installation of crankshafts bearings


Preceding work:

Engine removed and disassembled.

Main oil **passage** in crankcase open (01-130).

Clean oil passages in crankcase and in crankshaft.

Check crankshaft for cracks, dimensional tolerance, hardness and concentricity (03-318).






- |   |  |
|---|--|
| Crankshaft bearing covers (2 and 2 a) ..... | install without bearing shells, pay attention to markings, tighten. Hex. bolt 90 Nm, stretch bolt, initial torque 55 Nm, angle of rotation torque 90° (steps 1 and 2). |
| Basic bore .....                            | measure conicity in direction A, B and C (step 3).   |

Crankshaft bearing shells (24 and 24 a) . . . . .	insert, adhere to tightening torques (step 4).
Bearing diameters . . . . .	measure and note values (step 5).
Crankshaft (1) . . . . .	measure crankshaft bearing journals, determine bearing play (step 6).
Thrust bearing journals . . . . .	measure width and match appropriate thrust washers (step 7).
Bearing shells (24) . . . . .	oil with engine oil and insert crankshaft (step 8).
Thrust washers (23) . . . . .	oil and fit into grooves of thrust bearings, pay attention to oil grooves (step 9).
Thrust bearing cover (2a) . . . . .	oil together with thrust washers (23 a) and install (step 10) .
Crankshaft bearing cover (2) . . . . .	install, hexagon bolt, 90 Nm, stretch bolt (3 a), initial torque 55 Nm, angle of rotation torque 90° (steps 11 and 12).
Crankshaft bearing end play . . . . .	measure. Check ease of movement of crankshaft (steps 13 and 14).
Conrod . . . . .	recondition and check angles (03-313).
Conrod bearing shells (31 and 31 a) . . . . .	insert, initial torque 30 Nm, angle of rotation torque 90° (step 16).
Bearing diameter . . . . .	measure and note value (step 17).
Wrist pins . . . . .	measure, determine bearing play (step 18) .
Piston . . . . .	install on conrod (pay attention to installation position and install (03-316).
Conrod bearing cover (26) . . . . .	install, initial torque 30 Nm, angle of rotation torque 90° (step 20).
	<b>Caution!</b>
	Note step 20.



## Special tools



## Commercial tools

---

Quick caliper for internal measurements, dia. 40 – 60 mm	e. g. Hahn und Kolb Borsigstraße 50 D-7000 Stuttgart 30 Order No. G 222 K
Quick caliper for internal measurements, dia. 60 – 80 mm	Order No. G 322 K
Bow-type measuring bolt 25 – 50 mm	Order No. 31346 025
Bow-type measuring bolt 50 – 75 mm	Order No. 31346 050

---

## Data

Crankshaft normal size and repair sizes	Crankshaft bearing journal dia.	Thrust bearings Matched thickness of thrust washers	Crankshaft journal width at thrust bearing	Wrist pin dia.	Wrist pin width
Normal size	<u>57.960</u> <sup>1)</sup> 57.965  <u>57.955</u> 57.960  <u>57.950</u> <sup>1)</sup> 57.955	4.15 or 4.20	<u>28.500</u> 28.521 or <u>28.600</u> 28.621	47.955 47.965	28.000 28.084
Normal size I	<u>57.945</u> <sup>1)</sup> 57.950  <u>57.940</u> 57.945  <u>57.935</u> <sup>1)</sup> 57.940				
1st repair size	<u>57.705</u> 57.715	4.25 or 4.35 or 4.40	<u>28.700</u> 28.721 or <u>28.900</u> 28.921 or <u>29.000</u> 29.021	47.705 47.715	up to 28.30
2nd repair size	<u>57.455</u> 57.465			<u>47.455</u> 47.465	
3rd repair size	57.205 57.215			47.205 47.215	
4th repair size	<u>56.955</u> 56.965			46.955 46.965	

<sup>1)</sup> Colored dots on the crank webs or counterweights next to the crankshaft journals: blue, yellow, red.

## Basic bore and bearing play

	Crankshaft bearings	Conrod bearings
Basic bore dia.	<u>62.500</u> 62.519	<u>62.500</u> 62.519
Basic bore width at thrust bearing	<u>23.979</u> 24.000	-
Conrod width	-	<u>22.000</u> 21.948
Permissible out-of-roundness and conicity of basic bore	0.02	0.02
Radial bearing play	when new	0.025 – 0.045
	wear limit	0.070
Axial bearing play	when new	0.06 – 0.22
	wear limit	0.30

## Notes

Engine removed and disassembled.

Main oil passage in crankcase open (01-130).

Oil passages in crankcase and in crankshaft carefully cleaned.

Crankshaft checked for cracks, hardness, dimensional tolerance and concentricity (03-318).

Normal bearing shells and **thrust washers** are installed on the 3rd crankshaft bearing (thrust bearing).


The thrust washers absorb the axial forces of the crankshaft.

The thrust washers (23 and 23a) inserted in the crankcase and in the bearing cover on both sides are each identical.

The thrust washers each have two retaining lugs in the bearing cover as an anti-twist lock and to avoid assembly errors, the bottom lugs being fitted off-center. In addition, all the thrust washers are chamfered at one end.

When repairing crankshafts, the thrust bearing journals must be reground in the width to one of the dimensions stated in the table (Section "Data").

- 1 Crankshaft
- 2 Bearing cover
- 3 M 12 x 60 bolts (1st version)
- 3a M1 1 x 62 collar bolts (2nd version)
- 4b Washer
- 23 Thrust washer in crankcase
- 23a Thrust washer in bearing cover
- 24 Bearing shell in crankcase
- 24a Bearing shell in bearing cover



Thrust washers of the same thickness must always be installed on both sides.  
 It is not permitted to grind thrust washers.  
 The thrust washers are available only as sets as replacement parts. A set consists of one top and one bottom thrust washer (23 and 23a).


Matching crankshaft bearing shells to crankcase

Crankshaft journal bearing <sup>1)</sup>	Basic bores in crankcase		
	1 chisel marks	2 chisel marks	3 chisel marks <sup>2)</sup>
	Matching bearing shells with color coding		
blue	blue	yellow	yellow
yellow	blue	yellow	red
red	yellow	yellow	red


<sup>1)</sup> Colored dots on the crank webs or counterweights next to the crankshaft journals.  
<sup>2)</sup> Chisel marks in mating face of crankcase at oil sump end next to basic bore.

The normal size crankshaft bearing shells with the color coding blue, yellow and red are supplied as replacement parts. They should be matched according to the table. The bearing plays do not therefore need to be measured.


Chisel marks for matching crankshaft bearing shells




In June 1986 the crankshaft bearings were modified from 24 mm to 20 mm (size "B").




At the same time, the crankshaft bearing covers were reduced in height by 8 mm ( $H = 40$  mm).



- |               |         |
|---------------|---------|
| A 1st version | H 48 mm |
|               | B 24 mm |
| B 2nd version | H 40 mm |
|               | B 20 mm |




Likewise, the bolts of the crankshaft bearing covers were converted to M 11 × 62 twelve-sided stretch bolts with collar. Previously, M12 × 70 hexagon bolts.



- |                                      |
|--------------------------------------|
| A M12 x 70 hexagon bolts             |
| B M11 x 62 twelve-sided stretch bolt |

In view of the narrower crankshaft bearings, 4.15 mm thick thrust washers are installed on crankshaft bearing 3 (thrust bearing).




- |                                |
|--------------------------------|
| A 2.15 mm thick thrust washers |
| B 4.15 mm thick thrust washers |


**Standard implementation: 06186**

Model	Engine	Engine End No.		Vehicle Ident End No.	
		Manual transmission	Automatic transmission	A	F
201.024 (USA)	102.985	003938	036445		246820

During the period November through December 1987 and December 1987 through January 1988, single-section thrust washers from two different suppliers were installed.



A Two-section thrust washers



B Single-section thrust washers


## Matching crankshaft bearings, installing crankshaft

### Note

These operations should be performed if the dimensions of the crankshaft journals or of the basic bearing bores in the crankcase and at the conrod are not known, e.g. if the crankshafts have been remachined.


All the bearing covers fit into the side of the crankcase (arrows) and are attached each with 2 bolts.

The fit (arrows) is offset from the center so that the bearing covers can only be installed in one position.




In addition, they are marked from front to rear with the code numbers 1, 2, 4 and 5 (arrows), with the exception of the thrust bearing covers,, and must not be interchanged or replaced.


- 1 Install crankshaft bearing covers without bearing shells.
- 2 Oil fastening bolts for crankshaft bearing covers and tighten to 90 Nm (hexagon bolts) or 55 Nm initial torque and 90° angle of rotation torque (stretch bolts), respectively.




- 3 Measure basic bore in two planes in the direction A, B and C (conicity).  
If a basic bore exceeds the specified value or is conical, dress the mating face of the bearing cover on a surface plate to max. 0.02 mm.



4 Insert crankshaft bearing shells, install bearing covers, screw in fastening bolts and tighten to 90 Nm (hexagon bolts) or 55 Nm initial torque and 90° angle of rotation torque (stretch bolts), respectively.



P03-2019-13




P03-0055-57

- A Bearing shells in crankcase
- B Bearing shells in bearing covers
- C Thrust bearings with thrust washers




5 Measure and note bearing diameters.



6 Measure crankshaft bearing journals, determine radial play of crankshaft bearings.


Note

Bearing play can be corrected by replacing the bearing shells (refer to table for matching crankshaft bearing shells to crankcase).




7 Measure width of thrust bearing journal and match appropriate thrust washers (refer to table, Section "Data").

8 Oil bearing shells and crankshaft with engine oil and insert crankshaft.




9 Oil thrust washers with engine oil and fit the grooves on the thrust bearing (crankcase).



**Caution!**

The two oil grooves (arrows) in the thrust washers must be facing the crankshaft webs.




10 Install thrust bearing cover.

**Caution!**

Oil thrust washers with engine oil and place into the grooves on the thrust bearing cover. The two oil grooves in the thrust washers must be facing the crankshaft webs.

When installing the thrust bearing cover, hold both thrust washers tight.




11 Install crankshaft bearing cover.

12 Tighten fastening bolts of bearing covers to 90 Nm (hexagon bolts) or 55 Nm initial torque and 90° angle of rotation torque (stretch bolts), respectively.

13 Measure end play of crankshaft bearings.

14 Rotate crankshaft by hand and check whether it runs freely.



## **Matching conrod bearings and installing conrod**

---

15 Recondition conrod and check angles of bearing bores relative to each other (03-313).

16 Insert conrod bearing shells. Install conrod bearing cover with bearing shell and tighten conrod bolts to an initial torque of 30 Nm and angle of rotation torque of 90°.

Note


Conrod bearing shells are supplied only in the yellow version.

17 Measure bearing diameter and note.

18 Measure wrist pins, determine radial play of conrod bearings.

**Note**


If the conrod bearing play exceeds the specified value, dress mating face of conrod bearing cover on a surface plate to max. 0.02 mm.



19 Fit pistons to conrod and install (03-316).

**Note**

The conrod must be installed on the pistons so that the **chamfered** splash bore in the small end bearing (arrow) and the arrow in the piston crown are facing the direction of travel.




20 Tighten conrod bolts to an initial torque of 30 Nm and angle of rotation torque of 90°.

**Caution!**

Remove oil pump, clean, replace, if necessary, oil pump gears and drive sleeve (18-210). Remove oil pressure relief valve and check ease of movement of pistons (18-215). Remove oil filter (18-110), disassemble and clean.

Install initial operation oil filter element. After 1000 – 1500 km, change engine oil and oil filter element.



## 03-324 Replacing front crankshaft radial seal


Preceding work:

Drain coolant (20-010).

Remove radiator (20-420).




Remove poly V-Belt (13-342).

Remove belt pulley and vibration damper (03342).



Radial seal (45) .....	remove, replace and install (steps 1, 3 and 4)
Spacer ring (7) .....	check, replace if necessary (step 2).
Mounting hole .....	clean, check.

## Special tools




## Notes

Since August 1986 (implementation of use of double roller chain) a 4 mm narrower radial seal has been installed.

Size "C" 8 mm (previously 12 mm).

For the same reason, the mounting in the timing case cover (D) was made 3.4 mm flatter.


Size "D" 9.8 mm (previously 13.2 mm).



## Standard implementation:08/86 radial seal

Model	Engine	Engine End No.		Vehicle Ident End No.	
		Manual transmission	Automatic transmission	A	F
201.024 (USA)	102.985	004069	038196		261571

As a result of the modified installation position of the dust lip on the narrower radial seal, the chamfer on the vibration damper is shorter. Size "E" 0.8 mm (previously 2 mm).



Standard implementation: 08/86 vibration damper

Model	Engine	Engine End No.		Vehicle Ident End No.	
		Manual transmission	Automatic transmission	A	F
201.024 (USA)	102.985	004202	039381		267452

A radial seal of a further manufacturer was installed for a certain period.

Identification:      outer ring black  
                                  inner ring red

## Removal and installation

### Note

Before replacing the front crankshaft radial seal, it is necessary to determine whether the leak is occurring at the timing case cover itself (shrink holes, cracks).


This is done by cleaning the bottom area of the timing case cover free of oil, drying and spraying it with "MB contrast spray white",

Part No. 009 989 03 59. Run engine and pinpoint oil leak after 2 – 5 minutes.

1 Pry radial seal (45) out of the timing case cover with a screwdriver.


When performing the step, ensure that the crankshaft journal and the mounting hole in the timing case are not damaged. Cover over crankshaft journal with a rag.

Deburr mounting hole, if necessary.





- 2 Check whether the sealing lip of the radial seal has worn at the spacer ring (7) (groove). If necessary, remove spacer ring with the puller 102 589 00 33 00.  
If necessary, install new spacer ring.



- 3 Oil the sealing lip of radial seal (45).


**Caution!**

Do not use any grease. Grease prevents the inclined webs on the sealing lip from positioning.

- 4 Pull in radial seal with an installation tool.

**Installation instruction**

Use **special** tool 102 589 00 14 00 on engines with single roller chain, use additionally the 'spacer ring 102 589 01 14 00 (01) on engines with double roller chain.




## 03-327 Replacing rear crankshaft radial seal

Preceding work:


Removing transmission (26-020 or 27-600).

Removing flywheel or driven member (03-410).




Radial seal (20) .....	remove, replace and install.
Mounting hole .....	clean, check.
Sealing lip .....	oil.
Leaks when engine running .....	check.

## Special tool



### Notes

The sealing lip of the replacement radial seal is offset to the inside by 3 mm so that it does not run in a groove which may have been produced on the running surface on the crankshaft by the standard radial seal.



A Standard radial seal  
B Repair radial seal

The radial seal is installed into the end cover flush without any sealant.

Oil leaks can be determined after spraying the cleaned and dried surrounding area with Mercedes-Benz contrast spray white, Part No. 000 989 03 59.


## Removal and installation

1 Press radial seal out of the end cover with a screwdriver.

When performing this step, ensure that the crankshaft flange and the mounting hole in the end cover are not damaged. Cover over crankshaft flange with a rag.

2 Check running surface for radial seal on the crankshaft for signs of damage.

3 Clean mounting hole in the end cover for the radial seal, deburr if necessary.




4 Screw inner part of installation tool onto crankshaft flange.


5 Oil sealing lip of radial seal.

### **Caution!**

Do not use any grease. Grease prevents the inclined webs on the sealing lip from repositioning.




6 Install radial seal (arrow) over the inner part of the Installation tool.



7 Press the radial seal (arrow) into the end cover as far as the stop with the outer part of the installation tool.

**Caution!**

The radial seal must be positioned exactly at right angles to the crankshaft flange or inner part of the installation tool to ensure that it provides a proper seal.




8 Check for leaks with engine running.

## 03-330 Removal and installation of grooved ball bearing in crankshaft

Preceding work:



Removing transmission (26-020 or 27-600).

Removing clutch (25050).




Grooved ball bearing (19) and locking ring (21) . . . withdraw, special tool 000 589 33 33 00 and 000 589 25 33 00.  
Before installation, coat outer race of grooved ball bearing with adhesive 002 989 94 71.  
Knock in grooved ball bearing as far as the stop, outer race flush.

## Special tools




## Removal and installation

- 1 Withdraw grooved ball bearing with locking ring from the crankshaft, special tool 000 589 33 33 00 and 000 589 25 33 00.



- 2 Coat the new grooved ball bearing with the adhesive 002 989 94 71 and knock the outer race with a suitable drift to insert it into the crankshaft as far as the stop.

- 3 Knock in locking ring (132) flush.




## 03-342 Removal and installation of vibration damper or hub and belt pulley

Preceding work:

Draining coolant (20-010).





Removing radiator (20-420).

Removing poly V-belt (13-340).



Retaining lock on starter ring gear	.....	remove and install, special tool 601 589 02 40 00.
Belt pulley (13)	.....	unbolt, bolt on, 25 Nm.
Hexagon bolt (8)	.....	unscrew, bolt on, 300 Nm.
Shock absorber (28)	.....	Unbolt at bottom, bolt on (step 4) and press up, 25 Nm.
Vibration damper (11)	.....	pull off, special tool 601 589 08 33 00, fit on.

### Special tools





## Commercial tool


3/4" square socket to 1/2" square driver coupler

e. g. Hazet  
D-5630 Remscheid  
Order No. 1058 R-I

On vehicles with air conditioning/automatic climate control, the belt pulley (13) was installed with a hub with rubber part (38, damping part) with ball bearing (40) up to December 1984.

The uneven running of the crankshaft, particularly at low engine speeds and during cutin surges of the A/C compressor, are damped by the coupling so that the V-belt runs practically slip-free on the belt pulley.


- 1 KW Crankshaft
- 1ZK Crankcase
- 2 Oil pump outer gear
- 5 Crankshaft gear
- 6 Straight pin 3 x 5 mm
- 7 Spacer ring
- 8a M18 x 1.5 x 75 stretch bolt
- 9 Woodruff key
- 10 Belleville spring washer
- 10P Oil pump inner gear
- 11 Vibration damper
- 13 Belt pulley
- 15b M6 x 13 bolts
- 22 Oil pump drive sleeve
- 26 Oil sump
- 38 Hub with rubber part and steel ring
- 39 Flange
- 40 Ball bearing
- 41 Locking ring
- 42 End cover
- 44 Timing case cover
- 45 Radial seal



In order to provide greater clearance for the top shock absorber of the poly V-belt tensioning device, the shape of the vibration damper has been modified.

Size "a" = 133.1 mm dia., previously 145 mm dia.

A 1st version  
B 2nd version




### Standard implementation: 10/87

Model	Engine	Engine End No.	
		Manual transmission	Automatic transmission
201.028	102.985	018810	061766


The spacer ring on the crankshaft was made 3.65 mm narrower with implementation of the double roller chain.

### Removal and installation


- 1 Attach retaining lock 601 589 02 40 00 with two bolts to the oil pan (arrows).



2 Remove bolts (15) and take off belt pulley (13). Tightening torque 25 Nm.




3 Remove bolt (8) and take off Belleville spring washers (10).




### Installation Instruction

Oil bolt threads and Belleville spring washers.  
Install Belleville spring washers with curved side facing bolt head.




4 Remove bolt (34) for bottom shock absorber mounting and swing shock absorber (28) upwards. Tightening torque 25 Nm.



5 Pull off vibration damper (11) with the puller 103 589 00 33 00.

**Installation instruction**

When installing the vibration damper, check whether the groove in the hub is aligned with the Belleville spring washer in the crankshaft.




## 03-345 Checking and correcting setting of TDC pulse generator

Preceding work:

Removing poly V-belt (13-342).

Removing cylinder head cover (01-406).

Removing spark plugs (15-018).



Fan and fan coupling .....	remove and install (step 1).
No. 1 cylinder piston .....	set to ignition TDC (step 2).
No. 1 cylinder rocker arm bearing bracket .....	remove and install, 20 Nm (step 3).
Valve spring .....	remove from 1st intake valve, install (05-250).
Valve stem seal .....	remove from 1st intake valve, install (step 5 and 05-270).

TDC setting ..... measure by attaching dial gauge holder 363 589 02 21 00 to cylinder head. Mount valve on piston crown. Turn back crankshaft to approx. 10° before TDC of No 1 cylinder. Inset dial gauge in holder. Fit tracer pin of dial gauge onto valve stem with preload of 2 mm. Slowly turn crankshaft in direction of rotation of engine until the large pointer stops (TDC setting, steps 6 through 11).

Hexagon nut ..... unbolt at TDC pulse generator, withdraw TDC pulse generator (step 12).

Dial gauge ..... loosen and set preload of 5 mm, position scale of gauge to "0" (step 13).









Turn crankshaft ..... until dial gauge has moved back by 2.85 mm or 3.07 mm, respectively (step 14).

Fixing device ..... Insert special tool 119 589 00 21 00 into setting slide. The pin in the vibration damper must engage in the groove of the fixing device; correct setting slide, if necessary (steps 14 through 19).

**Data**

Piston travel at crankshaft setting 20° after TDC	measured over intake valve	2.85 mm
	measured directly at piston crown	3.07 mm

## Special tools



## Commercial tool


Dial gauge A 1 DIN 878

e. g. Mahr  
D-7300 Esslingen  
Order No. 311000

## Notes

The TDS pulse generator with holder (1) is attached to the timing case cover.

The pin in the vibration damper or on the belt pulley must be positioned exactly below the TDC pulse generator at a crankshaft setting of 20° after TDC.




The adjustment of the TDC pulse generator must be checked or corrected:

- When replacing the crankshaft or the vibration damper.
- When replacing the timing case cover.
- When installing parts to reconditioned engines.


The crankshaft setting 20° after TDC is determined from the piston travel, starting from ignition TDC of No. 1 piston.

The piston travel is measured either with the intake valve of No. 1 cylinder mounted on the piston crown and dial gauge or, if the cylinder head is removed, directly by mounting the dial gauge pin on the piston crown.




## Checking


1 Remove and install fan shroud (1) and fan (75), tightening torque of bolt (80), 25 Nm.



2 Set engine to ignition TDC of No. 1 cylinder.




3 Remove and install rocker arm bearing bracket (61) by unscrewing oil pipe. Tightening torque of bolts (63), 21 Nm.






4 Remove and install valve spring at No. 1 intake valve (05-250).




5 Remove and install valve stem seal of No. 1 intake valve. Oil new valve stem seal and press on by hand. Mount assembly sleeve on the valve stem for performing this step (05-270).



6 Mount valve on piston crown.


7 Turn back crankshaft to approx.  $10^\circ$  before TDC of No. 1 cylinder.

8 Bolt dial gauge holder 363 589 02 21 00 with threaded sleeve onto cylinder head set bolt at front left.



**Note**


With cylinder head removed, mount a magnetic dial gauge holder onto the mating face of the crankcase.




9 Insert dial gauge with extension.

10 Mount dial gauge with 2 mm preload onto the valve stem or piston crown.

11 Slowly turn crankshaft in direction of rotation of *engine* until the larger pointer of the dial gauge stops (TDC setting).




12 Unscrew hexagon nut (1a) and withdraw TDC pulse generator (1).



13 Loosen dial gauge and mount extension with 5 mm preload onto the valve stem or piston crown. Turn scale of gauge until the large pointer is at zero.


14 Turn on crankshaft in direction of rotation until the dial gauge has moved back by the appropriate value (data in table).



15 Position fixing device 119 589 00 21 00 into the setting slide (2).

The pin on the vibration damper must engage in the groove of the fixing device (1).

If the pin does not engage, adjust position of setting slide.




## Adjustment

---

16 Loosen nut (2a) and move setting slide (2) far enough for the pin on the vibration damper to engage in the groove of the fixing device.

17 Tighten nut (2a) and withdraw fixing device.




18 Insert TDC pulse generator and bolt on.

19 Remove dial gauge and dial gauge holder.

## 03-350 Removal and installation of crankshaft gear

Preceding work:  
 Removing timing case cover (01-210).  
 Removing chain tensioner (05-310).



Timing chain (21), camshaft gear (4) and  
 crankshaft gear (5 or 5a) .....  
 Camshaft gear (4) .....  
 Tensioning rail (22) .....

mark relative to each other (steps 1 and 2).  
 remove and place timing chain in chain box  
 (step 3). Install (step 10), 80 Nm.  
 pull off and insert.

### Note





Drill bearing pin (26) of engines with double  
 roller chain, tap M6 thread and knock out with  
 impact extractor 115 589 12 33 00 and  
 extension 100 589 00 43 00.  
 When installing tensioning rail, insert new  
 bearing pin together with tensioning rail  
 (steps 4 and 9).

Crankshaft gear (5 or 5a) .....

pull off with puller 102 589 05 33 00 together with oil pump drive sleeve.

Transfer colour marking to new crankshaft gear. Knock in crankshaft gear, if necessary, with drift 116 589 07 15 00, pay attention to straight pin (6) (steps 5 through 8).

### Special tools




### Note


As of January 1988 a double roller timing chain has been installed.

## Removal and installation

1 Mark timing chain and camshaft gear relative to each other.




2 Mark timing chain and crankshaft gear relative to each other.



3 Unbolt camshaft gear and place timing chain in chain box.


4 Pull tensioning rail (22) off bearing pin (26) .



### Note


**On** engines with double roller chain, knock out bearing pin of tensioning rail with the impact extractor 115 589 12 33 00 and the extension 100 589 00 43 00.

To perform the step, tap an M6 thread approx. 10 mm deep into the bearing pin.



5 Pull off crankshaft gear and oil pump drive sleeve with the puller 102 589 05 33 00.


6 If the crankshaft gear is replaced, transfer color marking from the old to the new crankshaft gear.



7 Install crankshaft gear onto crankshaft. If this proves difficult, knock in with the impact drift 116 589 07 15 00.


Pay attention to the straight pin for locating, when performing this step.

8 Insert drive sleeve.




9 Insert tensioning rail.

On engines with double roller chain, insert tensioning rail and knock in new bearing pin as far as the stop.




10 Install camshaft gear (pay attention to color marking), tightening torque 80 Nm.

11 Check for leaks with engine running.




## 03-410 Removal and Installation of flywheel or flex plate

Preceding work:  
 Removing transmission (26-020 or 27-600).  
 Removing clutch (25-050).



Retaining lock on starter ring gear .....	remove and install, special tool 601 589 02 40 00 (step 2).
Stretch bolt (18) .....	unbolt, bolt in, check length/stretch shaft dia., initial torque 30 Nm, angle of rotation torque <b>90°</b> , with two-mass flywheel 50 Nm, angle of rotation torque <b>90°</b> (steps 6 and 7).
Flywheel (16) or flex plate (43) with spacer disc (44) .....	detach, attach (step 5).

### Special tools






## Stretch bolt


Part No.		102 <b>032 00</b> 71	103 032 00 71 <sup>1)</sup>
Thread dia. D		M10×1	M10×1
Thread shaft dia. d	when new	8.5 -0.2	8.5 -0.2
	minimum dia.	8.0	8.1
Length L	when new	22 ±0.2	57 ±0.2
	maximum length	22.5	

<sup>1)</sup> Stretch bolt with two-mass flywheel



## Notes

The engines 102.922/924/962/963 have the same flywheels (standard flywheel). Compared to this standard flywheel, the flywheel of engine 102.985 is lighter and the hole circle for the tapped holes for mounting the clutch are larger. The flywheels must not be interchanged and can be replaced without the need for static or dynamic balancing.



**A** Engines **102.922/924/962/963**

D 253 mm  
D1 223 mm  
H 58.6 mm


**B** Engine **102.985**

D 265 mm  
D1 237 mm  
H 57 mm

The flex plate of the engines with automatic transmission is identical on all engines. Flywheel and flex plate with ring gear can be replaced without the need for static or dynamic balancing.


Arrangement of flex plate on crankshaft of engines with automatic transmission.

- 17 Ring gear
- 18 M10 x 1 x22 stretch bolt
- 43 Flex plate
- 44 Spacer disc
- 44a Spacer disc (bonded on)




Arrangement of flywheel on crankshaft of engines with manual transmission.

- 16 Flywheel
- 17 Ring gear
- 1a M10 x 1 x22 stretch bolt




With the distributor ignition (DI - formerly EZL), the flywheel or the flex plate was provided with two segments (A) offset by 180°. As the segments rotate past the position sensor this produces an alternating voltage as a result of induction. If the segments are damaged, replace the flywheel or the flex plate.

Flywheel of manual transmission




Flex plate of automatic transmission




## Removal and installation

1 Remove end cover (30) from the rear of the oil pan. Remove bolts (arrows), bolt in, tightening torque 10 Nm. Press off end cover with screwdriver, fit on.



2 Attach retaining lock 601 589 02 40 00 with both bolts (arrows). The pins on the retaining lock must mesh into the ring gear teeth.


3 Unscrew stretch bolts (18). Take off flywheel or driven member with bonded spacer disc (44a) and spacer disc (44).




4 Check stretch bolts (see table).

5 install flywheel or flex plate (43) with bonded disc and disc (44), pay attention to centering of installation pin.

6 Bolt in stretch bolts (18) and tighten to an initial torque of 30 Nm or 50 Nm, respectively, for the two-mass flywheel.




7 Torque stretch bolts (18) in a single operation by the specified angle of rotation torque of 90°.



## 03-420 Remachining flywheel

Preceding work:  
Removing flywheel (03410).



### Data

Engine	102.985	
Distance a	19.4 – 19.5 mm	
Distance b	when new	16.6 mm
	up to for repairs	15.5 mm
Permissible axial runout at clutch face or clutch flange face	0.05 mm	

### Notes

The two-mass flywheel cannot be machined and is only available as a complete replacement part. Flywheels for manual transmissions which have scorch marks, scoring or cracks in the clutch face, should be machined by precision turning.

---

If grooves or cracks are deeper than the maximum permissible material removal, the flywheel must be replaced.

If the clutch face A is machined, the mounting face B must be machined by the same amount in order to maintain the distance a.


The size b must be maintained as a minimum when performing repairs.

The flywheel must be properly clamped for machining to ensure that the permissible axial runout of 0.05 mm is not exceeded.

After machining, the clutch face must not show any shrink holes or chatter marks.

## 03-430 Replacing ring gear on flywheel

Preceding work:  
Removing flywheel (03-410).



Ring gear (17) .....	Drill old ring gear and snap open with a chisel or heat rapidly and then remove immediately. Heat new ring gear to 220 °C and fit onto the flywheel immediately. Pay attention to instruction. Lateral <b>runout</b> at ring gear max. 0.4 mm.
Flywheel (16) .....	Centering collar dia. (a) for ring gear <b>275,31–275,39</b> mm. Clean contact surface of ring gear at flywheel before installation on ring gear.
Flex plate (43) .....	This ring gear is welded on and cannot be replaced. Replace driven member complete.

### Commercial accessories

Temperature measuring chalk  
Colour No. **2815/220** (white) Thermochrom

e. g. AW **Faber-Castell**  
D-8504 Stein bei **Nürnberg**

**Notes**

The ring gear is hardened. For this reason, do not exceed a temperature of 220 °C (yellow annealing colour) at any point when heating. This is only reliably possible by using a heating plate or heating oven.

Use a temperature measuring chalk corresponding to the instructions if possible.

Only use a flame in exceptional cases.

Coat only the inside of the ring gear for this purpose.

After replacing a ring gear, the flywheel does not need to be balanced.

To avoid damage to the ring gear, a ring gear with axially chamfered teeth was installed for a brief period to vehicles with automatic transmission.

**Standard implementation:** April – July 1986 standard

Model	Engine	Engine End No.	
		Manual transmission	Automatic transmission
201.028	102.985		033406 – 038268