



Mercedes-Benz

Service

Service Manual Supplement Engine 102.983

Mercedes-Benz of North America, Inc.

S-2347-SUP

© Mercedes-Benz of North America, Inc., 1988, Reprinted 1993.

All rights reserved. Reproduction by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system or translation in whole or part is not permitted without written authorization from the publisher.

Published by Mercedes-Benz of North America, Inc.
Printed in U.S.A.

Order No. S-2347-SUP

Introduction

This supplementary manual is the product of existing technical publications. It is intended to supplement Service Manual Engine 102 and covers those areas where the **16-valve** engine differs from the standard 8-valve engine. In Group 07.3, additional information covers fuel system changes for 1987.

The material in this manual is divided according to the Mercedes-Benz Component Group System as outlined on the GROUP INDEX page. This page will quickly direct the reader to the Major Component Group.

Mercedes-Benz of North America, Inc. recommends that repairs to, and maintenance of Mercedes-Benz automobiles be performed by **trained Mercedes-Benz personnel** at authorized Mercedes-Benz dealerships.

The information contained in this special publication is ordinarily issued by Mercedes-Benz of North America, Inc., in conjunction with supplementary service literature and special tools supplied **only** to its authorized dealers. The information outlined herein is intended for use by **trained Mercedes-Benz service and dealership personnel**. This manual can also be useful for Mercedes-Benz owners in diagnosing vehicle systems and performing repairs.

Special tools required in performing certain service jobs are identified in the manual and are recommended for use. Any part numbers given are only used for identification and easier differentiation between individual components, and are not intended for ordering purposes.

All procedures, **illustrations** and specifications contained in this manual were based on the latest information available at the time of publication. All rights are reserved to make production, design and specification changes at any time, without notice and without obligation to give notice. Any such changes will not be contained in this manual.

Caution!


The proper performance of service and repair procedures is essential for both the safety of the mechanic and the safe and efficient operation of the vehicle. The use of incorrect service procedures and tools may greatly increase the risk of personal injury and render the vehicle unsafe. The procedures in this manual are described in such a manner that the service may be performed safely and accurately.

However, it is a general assumption that the reader is familiar with basic automotive repair procedures and Mercedes-Benz vehicles. You should not attempt to use this manual if this is not the case.


Mercedes-Benz of North America, Inc. assumes no liability for any damage to person or property caused by the utilization of this publication to effect maintenance or repair work on Mercedes-Benz automobiles.

Table of contents

Engine 102.983			
Views of engine 102.983	7	07.3 Mechanically/electronically controlled gasoline injection system (CIS-E)	
Longitudinal and cross sectional views of engine 102.983	8	General	37
00 General, technical data	9	Components and function	39
01 Crankcase, cylinder head, crankcase ventilation		Mixture preparation	40
Cylinder crankcase	13	Component locations and electrical functions	40
Oil pan	13	Checking electrical components of CIS-E injection system	47
Cylinder head	14	Test and adjustment data	60
Camshaft bearings	14	Model year 1987 changes	61
Valve guides	15	09 Air filter	67
Valve seat rings	16	13 Belt drive	
Spark plug locations	16	Single-belt drive	68
Core plugs	17	14 Intake manifold, exhaust manifold	69
Connections	17	15 Electrical system, engine	
Cylinder head gasket	18	Electronic ignition system with electronic timing adjustment (EZL)	70
Valve cover	18	Components of ignition system	70
Positive crankcase ventilation (PCV)	20	Removal and installation of high voltage distributor	73
Removal and installation of cylinder head	21	Testing EPL electronic ignition system	74
03 Crankshaft assembly		Spark plugs	75
Crankshaft	27	18 Engine lubrication	
Vibration damper	27	Lubrication circuit diagram	76
Flywheel, flex plate	28	Oil filling capacities	77
Pistons	28	Cup-type tappet and cam lubrication	77
05 Engine timing, valve train		Oil temperature gauge	77
Camshaft	30	20 Engine cooling	
Testing and adjusting values	31	Coolant pump	78
Valve arrangement	31	Thermostat housing and thermostat	78
Intake and exhaust valves	32	Fan clutch	78
Valve spring, valve keepers	32	Radiator	78
Valve stem seals	32	22 Engine mounts	79
Checking and adjusting valve clearance	33	30 Throttle control	80
Chain drive	33		
Camshaft sprockets	34		
Single roller chain	34		
Guide rail, tensioning rail	35		
Intermediate sprocket	35		
Hydraulic oil pump drive	36		





100-31585/1



100-30923

Longitudinal and cross sectional views of engine 102.983




This manual applies to the following passenger cars, model years 1986 – 1987.

Gasoline engines

Model Year	Model	Sales Designation	Engine
1986 – 1987	201. 034	190 E 2. 3-16	102. 983


Model 201.034

When ordering spare parts, please specify chassis and engine numbers.



- 1 Certification Tag (left door pillar)
- 2 Identification Tag (left window post)
- 3 Vehicle Identification No.
- 4 Engine No.
- 5 Body No. and Paintwork No.
- 6 Information Tag
California version
Vacuum line routing for emission control system
- 7 Emission Control Tag
- 8 Emission Control Tag
Catalyst Information (model year 1986)

Model year 1986



- 1 Certification Tag (left door pillar)
- 2 Identification Tag (left window post)
- 3 Vehicle Identification No.
- 4 Engine No.
- 5 Body No. and Paintwork No.
- 6 Information Tag
California version
Vacuum line routing for emission control system
- 7 Emission Control Tag

Model year 1987

Gasoline engine

Model	201.034
Sales designation	190 E 2.3-16 (Model Years 1986 - 87)
Engine	102.983
Operation	4-stroke spark ignition, mechanically/electronically controlled continuous fuel injection system with airflow sensor (CIS-E)
Number of cylinders	4
Cylinder arrangement	In-line 15 ° inclination
Bore/stroke mm	95.5/80.25
Total effective piston displacement cc	2299
Compression ratio	9.7 : 1
Firing order	I-3-4-2
Maximum speed rpm	6800 ± 50
Engine output (SAE)	
	kW/rpm 125/5800
	net bhp/rpm 167/5800
Maximum torque	
	Nm/rpm 220/4750
	net lb-ft./rpm 162/4750
Crankshaft bearings	5 (multi-component, anti-friction bearings)
Valve arrangement	Overhead, 4 per cylinder
Camshaft arrangement	2 overhead camshafts
Oil cooling	Oil-to-air-cooler
Cooling	Coolant circulation pump, thermostat with bypass line, fan with visco clutch, finned tube radiator
Lubrication	Pressure lubrication via gear type pump
Oil filter	Full flow filter
Air cleaner	Dry air filter with paper cartridge

Filling capacities

Model	201.034
Sales designation	190 E 2.3-16 (Model Years 1986 - 87)
Engine	102.983
Fuel tank/reserve approx. l	7018.5
During initial oil filling approx. l	5.5
During oil and filter change approx. l	5.0
Marks on dipstick max./min. approx. l	4.8/2.8
Cooling system with heater approx. l	8.0

Electrical system

Model	201.034
Sales designation	190 E 2.3-16
Engine	102.983
Battery	
Voltage	12 v
Capacity	62 Ah
Starter Bosch	12 v 1.5 kW
Alternator	14 V 70 A

Crankcase, cylinder head, crankcase ventilation

Crankcase

The crankcase corresponds with that of the engine 102.985, except for the following modifications.

The mounting bore for the TDC position indicator of the ignition system (arrow) is located above the starter mounting flange.




Fig. 01/1

The oil deflector plate fastened to crankshaft bearing caps 1 - 3 prevents splashing of oil at high engine speeds.




Fig. 01/2

Oil pan

The oil pan was reinforced by additional ribs on the bottom.

The low oil level switch was moved higher on the oil pan due to the lower oil quantity circulated through the engine.

Repair note

The oil pan can be removed without removing the engine.

Cylinder head

Cross flow cylinder head with roof-shaped combustion chambers.




Fig. 01/3

E = Intake
A = Exhaust

Camshaft bearings

Intake and exhaust camshafts are mounted directly in the cylinder head. The four split bearing bores for each camshaft are half in the cylinder head and in mounted bearing caps.

The shaft ends of the camshaft sprockets are mounted in the two bearings (1 and 6).




Fig. 01/4




Fig. 01/5

All bearing caps are identical. They are line bored together with the cylinder head and are identified with the numbers 1 to 10. During assembly jobs, the original installation position must be maintained.




Fig. 01/6

Installation position of bearing caps

Bearing cap 1 = bearing of exhaust camshaft sprocket (Fig. 01/5).

Bearing caps 2 - 5 = bearings of exhaust camshaft (Fig. 01/6).

Bearing cap 6 = bearing of intake camshaft sprocket (Fig. 01/5).

Bearing caps 7 - 10 = bearings of intake camshaft (Fig. 01/6).

The bearing caps are fastened to the cylinder head with M 8 studs, wave washers and nuts.

Tightening torque of nuts 21 Nm.

Repair notes

In case of seizing or excessive scoring on camshaft bearings, replace cylinder head and camshaft.

Replace only one bearing cap per camshaft since during simultaneous replacement of several bearing caps the camshaft may bind.

The bearing caps are correctly installed, if the stamped in code numbers are closest to the inner studs (Figs. 01/5 and 01/6).

Valve guides

The valve guides are located at an angle of 45° in relation to each other (Fig. 01/8) and are fitted in the cylinder head with an interference fit of 0.012 - 0.041 mm.

The OD (13 mm) is 1 mm smaller than on the other engines 102. They are also shorter.

Repair note

The finished valve guides are available in four repair sizes.




Fig. 01/7

58 Intake valve guide
(copper colored)
D = 13.023 - 13.041 mm
D1 = 7.000 - 7.015 mm
L = 45.5 mm
58a Retaining ring

59 Exhaust valve guide
(brass colored)
D = 13.023 - 13.041 mm
D1 = 8.000 - 8.015 mm
L = 42.9 mm
59a Retaining ring

Valve seat rings

The valve seat rings are press fitted in the cylinder head with an interference of 0.075 – 0.120 mm.




Fig. 01/8

- 56 Intake valve seat ring
 D = 39.100-39.120 mm
 D1 = 3.3 mm
 D2 = 39.000 - 39.025 mm
 H = 5.8 mm
- 57 Exhaust valve seat ring
 D = 34.100 - 34.120 mm
 D1 = 2.8 mm
 D2 = 34.000 - 34.025 mm
 H = 5.4 mm

Repair note

One repair size valve seat ring with a larger OD is available for intake and exhaust respectively.

Spark plug location

The spark plug with threads M 14 x 1.25 and tapered sealing seat is centrally located in the combustion chamber.

Repair note

Before unscrewing spark plugs clean out recesses with compressed air. This will help prevent dirt from entering the combustion chambers when removing the spark plugs.




Fig. 01/9

a Tapered sealing seat

Core plugs

The core holes in cylinder head are closed with 18.2 mm dia. sheet metal plugs (59), the front and lateral oil ducts with 5.2 mm dia. sheet metal plugs (57) and the bottom oil duct with a 5 mm dia. dowel pin (58).

Repair note

Leaking plugs can be replaced similar to the other engines 102. Refer to special tools section.




Fig. 01/12 Cylinder head front

- 57 Sheet metal plug 5.2 mm dia
- 58 Dowel pin, 5 mm dia.




Fig. 01/10 Cylinder head right side

- 57 Sheet metal plug 5.2 mm dia
- 59 Sheet metal plug 18.2 mm dia




Fig. 01/11 Cylinder head left side

- 47 Threaded pipe connector for coolant to heater core
- 57 Sheet metal plug 5.2 mm dia.
- 59 Sheet metal plug 18.2 mm dia.
- 81 Threaded pipe connector for crankcase ventilation coolant heating

Connections

A coolant return pipe (23) is inserted at the front of the cylinder head, leading through the timing chain housing to a coolant chamber.

Sealing

- In the coolant passage with O-ring (24)
- At the mounting flange with gasket (26)




Fig. 01/13

A threaded connection for coolant to the heater core (47) and one for the crankcase ventilation heating (81) are screwed into the cylinder head left rear corner (Fig. 01/11).


Cylinder head gasket

The cylinder head gasket does not require retorquing. There is only one gasket version for this engine, independent of cylinder dia. (standard, repair sizes + 0.5 mm dia. and + 1 .0 mm dia.).

The gasket has an adhesive strip on the sealing surface. It is identified by the stamped in part number and by the relief holes (arrows).

Caution:

Do not interchange this cylinder head gasket with those of other 102 engines.



101-30918


Fig. 01/14

Valve cover

The valve cover is made of a magnesium alloy and is laminated with black plastic on the outside.

The ignition cable channel cover is plastic (113). It is fastened with three plastic screws (114) and sealed with a rubber gasket. To prevent excessive tightening which could damage the cover, each screw has a special washer.

The oil filler cap is plastic (90).



101-30918/1

Fig 01/15


- 82 Hose connection for engine ventilation
- 83 Hose connection for engine ventilation with bypass bore 1.6 mm dia.
- 90 Oil filler cap
- 113 Ignition cable channel cover
- 114 Plastic screws (Tightening torque 1.5 - 2 Nm)

Inside/underside

The oil separator plate (85) for the engine ventilation is fastened with 8 screws and sealed with silicone adhesive.

Valve cover gasket (93) made of rubber (U section).

Rubber seal rings (112) for sealing spark plug recesses.



101-30918/1

Fig. 01/16

- 85 Oil separator plate
- 85a Oil drain tube
- 93 Valve cover gasket
- 112 Rubber seal rings


To make sure that the spark plug recesses and the ignition cable channels are not filled with water, e. g. during an engine wash, the valve cover has a drain hole at the rear (arrow, Fig. 01/15).

Assembly notes

The valve cover M6 cap nuts should be tightened crosswise and in several steps.

Tightening torque 9 Nm.

The ignition cable channel has guide ribs and symbols for correct installation of ignition cables.



101 - 28300

Fig. 01/17

Positive crankcase ventilation (PCV)

Operation

The engine blow-by gases flow from cylinder crankcase to oil separator (90) in the valve cover. The oil separated here flows back to the cylinder head through a drain pipe.

From the oil separator the engine blow-by gases flow into the combustion chambers depending on load condition (intake manifold vacuum) as follows:

Idle/decel

(high intake manifold vacuum)

Through bypass bore 1.6 mm dia. in hose connection (83) on the valve cover to idle speed air distributor (108) and through the insulating sleeve of the injection valves to combustion chambers.

Simultaneously, additional clean air is drawn in from air cleaner (111) via hose line (103a - 103c) and fed to the combustion chambers via the oil separator together with the blow-by gases.

Partial and full load operation

(low intake manifold vacuum)

Mainly via hose line (103a - 103c) to air cleaner clean side and with intake air to the combustion chambers.

To make sure that the vent line (103a - 103c) does not freeze at low outside temperatures, it is heated with coolant. The coolant line (106) is integrated in the vent line and is connected to the cylinder head via the supply line (104). The coolant is returned to the coolant pump (1) via return line (109).




Fig. 01/18

1	Coolant pump	107	Coolant connection line
83	Hose connection with 1.6 mm throttle	108	Idle speed air distributor
103a-103c	Vent lines	109	Coolant return line
104	Coolant supply line for crankcase vent line	110	Crankcase vent line
105	Idle speed air line	111	Air filter
106	Heating water line (copper tubing)		

Removal and installation of cylinder head

Note: Only repair instructions not described in microfiche Engine 102, Mechanical I, will be discussed in the following pages.

Tightening torques	Nm
Chain tensioner in crankcase	40
Camshaft sprockets	12
Camshaft bearing caps	
Exhaust manifold to cylinder head	
Thermostat housing to cylinder head	21
Coolant connecting pipe (cylinder head - thermostat housing) to cylinder head	
Support (exhaust manifold - transmission) to exhaust manifold	
Exhaust system to exhaust manifold	27
Valve cover	9

Removal

Air filter housing

Disconnect plug from intake air temperature sensor (124) and crankcase ventilation hose (103c) on air cleaner (121).

Remove nuts (122), lift housing at the rear until it is released from studs, slide back slightly (direction of arrow) and lift from air flow sensor.




Fig. 01/19

Oil dipstick guide tube

Remove screw (46) and rotate clamp (47) away from bracket (45). Pull out oil dipstick (42).




Fig. 01/20

Poly-V-belt drive

Loosen screw (25) by $\frac{1}{4}$ – $\frac{1}{2}$ turn, slacken poly-V-belt (27) by turning tensioning nut (24) counterclockwise. Remove poly-V-belt (27).




Fig. 01/21

Exhaust manifold

Remove screw (119) from support bracket (118) and loosen screws (120) on transmission.




Fig. 01/22

Valve cover

Remove screws (114) of ignition cable channel cover (113), remove cover, pull off spark plug connectors and put ignition cables aside.

Loosen hose clamp (128) and pull hose (103) from valve cover (81).

Pull hose (110) from valve cover, remove nuts (96) and remove valve cover.

Caution!

If the valve cover is stuck, do not strike with a hammer to loosen it, the valve cover may crack

Try to loosen the valve cover by pushing at one side with your hands; if necessary, carefully tap corners with a rubber mallet.




Fig. 01/24

Camshaft sprockets

Set engine to ignition TDC of 1st cylinder.

For this purpose, turn crankshaft until the bores in the camshaft sprockets (2 mm dia., arrows) are aligned opposite each other.

Mark camshaft sprockets (4A and 4E) and timing chain (21) in relation to each other.




Fig. 01/25

Remove alternator air duct. Disconnect wires to alternator at terminal block. Pull harness through component compartment wall and put aside with air duct.

Remove screw (722), loosen screw (723) and rotate alternator (724) away from engine.




Fig. 01/26

Unscrew chain tensioner (40) at hex. head (32 mm).




Fig. 01/27

Remove screws (241) and flange (239).




Fig. 01/28

Remove nuts (65) and remove bracket (27) together with slide rail (31).

Note: If installed, remove the sheetmetal bracket which is attached at the two front cylinder head bolts and two eyes at timing chain housing cover.




Fig. 01/29

Remove screws (10) (four, each sprocket), knock back camshaft (1A and 1 E) with a plastic hammer, remove nuts (65), remove bearing caps (61/1 and 61/6) and then remove camshaft sprockets (4A and 4E).




Fig. 01/30

Coolant return pipe between cylinder head and thermostat housing

Loosen hose clamp (38), remove screws (39), remove thermostat housing (29) and put aside.




Fig. 01/31

Remove screws (402) and pull return pipe (399) out of cylinder head.

Note: If the pipe cannot be pulled out by hand, slightly rotate (direction of arrow) and force off with two screwdrivers, also refer to Fig. 01/13.




Fig. 01/32

Installation

Prior to installation, measure shaft length (L) of double hex. socket head stretch bolts.

Double hex. socket head stretch bolt

Threads	Shaft length	
	New	Max. length (replace)
M12	110 mm	113 mm




Fig. 01/33

Torque specifications and tightening diagram for cylinder head bolts are identical to other engines 102.

Replace O-rings and flange gasket on coolant return pipe (cylinder head-thermostat housing).

Install intake camshaft sprocket first, then exhaust camshaft sprocket. Note markings on timing chain and camshaft sprockets.

Check marking of camshaft sprockets in ignition TDC position of 1st cylinder.

For mounting and tensioning of poly-V-belt refer to maintenance jobs section.

Crankshaft assembly

Crankshaft

The crankshaft is similar to the other engines 102 with respect to material and dimensions.

All crankpin fillet radii are hardened. On the other engines 102 only crankpins 3 and 4, as well as pin 1, at front end are hardened.




Fig. 03/1

- | | |
|-------------------------------|------------------------------|
| 1 Crankcase | 109 Woodruff key |
| 27 Oil pan | 110 Belleville washer |
| 48 Timing chain housing cover | 111 Vibration damper |
| 49 Seal ring | 113 Pulley |
| 104 Crankshaft | 116 Screws, M 8 x 16 |
| 105 Crankshaft sprocket | 301 Internal gear, oil pump |
| 106 Dowel pin 3 x 5 mm | 302 External gear, oil pump |
| 107 Spacer | 319 Driving sleeve, oil pump |
| 108 Screw, M 18 x 1.5 x 75 | |

A dowel pin (147) for locating the flywheel or the flex plate is inserted in the rear flange.




Fig. 03/2

Repair sizes are identical to the other engines 102.

Vibration damper (111)

Due to the higher engine speeds and the resulting higher load the adhesive surfaces between rubber and metal were designed larger than on the vibration damper of engine 102.985.

The TDC markings are located on the rubber surface.

Flywheel (manual transmission)

Due to higher engine speeds the material for the flywheel is of increased strength.

It is also lighter in weight than that of engine 102.985. The two 55° segments (A) on the back are located at an angle of 180° (Fig 03/3 and 03/4) in relation to each other. The installation position is fixed by a dowel pin (for bore refer to arrow).

Together with the position indicator in crankcase the segments are transmitting a signal to the control module of the ignition system.




Fig. 03/3

A Segments
Arrow Locating bore

Flex plate (automatic transmission)

Due to the higher loads, the flex-plate is reinforced with 2 mm thick steel rings riveted to the ring gear (engine 102.985 has one 2.4 mm thick steel ring).

The two 55° segments (A), spaced 180° apart (Fig. 03/3 and 03/4), produce together with the ignition position sensor in the engine block an alternating current signal which is transmitted to the ignition control module. Due to the segments, the flywheel or the flex plate must be assembled to the crankshaft in a specific fixed position. This position is determined by a dowel pin in the crankshaft flange.




Fig. 03/4

A Segments
Arrow Locating bore

Pistons

The light-alloy pistons are manufactured by a hot forging process to provide higher strength.

Four valve recesses are located on the flat piston top.

The piston play is 0.051 – 0.075 mm (on engine 102.985 = 0.016 – 0.040 mm).

Designation and repair sizes are identical to other engines 102.




Fig. 03/5 Piston top

Compared with rings of engine 102.985 the rectangular and baffle taper compression rings are lower in height by 0.25 mm. Ring height 1.5 or 1.75 mm. The chamfered oil control ring is made of a higher strength material.

The piston wrist pin has been reinforced.

ID 14 mm

Length 65 mm.

Contrary to engine 102.985 the connecting rods on this engine are guided at the crank pins.




Fig. 03/6

- 141 Rectangular ring, contact surface molybdenum-laminated, 1.5 mm high
- 142 Baffle taper compression ring, with precision turned contact surface (not laminated), 1.75 mm high
- 143 Chamfered oil control ring with expander, contact surfaces chromed

Engine timing, valves




Fig. 05/1

Camshaft

The hollow-bored camshafts are made of chilled cast iron and are left and right of identical design.

The bearings are supplied with oil through the longitudinal bore. At the rear end, the camshaft is closed by a sheet metal cap.

Each camshaft is mounted in four bearings (28 mm dia.).




Fig. 05/2

With the camshaft sprocket removed, the camshaft can be rotated or counterheld at the 24 mm hex. (arrows).

If the timing is correct, the bores (2 mm dia.) in the camshaft sprockets (arrows, Fig. 05/9) are opposite to each other in ignition TDC position of 1st cylinder.

Repair notes

When replacing *camshafts*, also replace *valve tappets*.

When removing and installing camshafts, note installation position of bearing caps. (Refer to Group 01, page 33).

Carefully and uniformly tighten fastening nuts of bearing caps.

Tightening torque 21 Nm.

Checking valve timing

Check valve timing on 1. cylinder:
 Check intake camshaft – begin of opening
 Check exhaust camshaft – end of closing

The test procedure is the same as on engine 110 (see repair instructions on microfiche, Engine 110, Mechanical II).

Slip gauge blade on intake camshaft in from outside and on exhaust camshaft from inside. Hold down cup-type tappet with suitable tool which has no sharp edges.

Minor deviations (approx. 4 – 5°) are within tolerance and cannot be corrected. If deviations are higher, e. g. due to timing chain elongation, install new chain.

Testing and adjusting values

Timing in crank angle degrees at 2 mm valve lift


Camshafts Code number ¹⁾	Intake valve opens after TDC closes after BDC		Exhaust valve opens before BDC closes before TDC	
	with new timing chain			
Left	7°	26"		
Right	-		32°	13°
with used timing chain (approx. 20 000 km, 12 500 mi)				
Left	8°	27"		
Right	-		31°	12°

¹⁾ Installed are selectively: 102 050 24 01 without code no. or 102 050 28 01 with code no. 25.

Valve arrangement

Fig. 05/3

- 55 Cylinder head
- 56 Valve seat ring, intake
- 57 Valve seat ring, exhaust
- 58 Valve guide, intake
- 59 Valve guide, exhaust
- 160E Camshaft, intake
- 160A Camshaft, exhaust
- 196 Intake valve
- 197 Exhaust valve
- 198 Valve spring
- 199 Valve keeper
- 200 Valve spring retainer
- 201 Thrust ring
- 202 Valve stem seal, intake valve
- 203 Valve stem seal, exhaust valve
- 219 Valve tappet
- 220 Thrust plate
- E Intake
- A Exhaust



The intake and exhaust valves (two each per cylinder) are mounted overhead at an angle of 45° in relation to each other. They are actuated by the intake or exhaust camshaft and case-hardened cup type valve tappets (219).

Intake and exhaust valves

Valve seat angle 45°

Intake valve

Valve seat and valve stem bath nitrited.

Exhaust valve

Valve seat is high quality sintered metal

Valve stem induction hardened and filled with sodium.




Fig. 05/4

196 Intake valve
 D = 38 mm ϕ
 D1 = 6.97 mm ϕ
 L = 111.65 mm

197 Exhaust valve
 D = 33 mm ϕ
 D1 = 7.96 mm ϕ
 L = 111.5 mm

Valve spring (198)

Each valve has a double progressive valve spring. The spring can be installed in either direction.

Color code: yellow-black.

Refer to special tool section for removal and installation tools.

Valve keepers (199)




Fig. 05/5

B (mm)	9
H (mm)	9.2 - 9.8

Caution

The valve keepers must not be interchanged with those of the other 102 engines.

Valve stem seals (202 and 203)

Valve stem seal	Material	Wire ring Color	ID "D"
Intake	Viton	black	6.3 mm
Exhaust	Viton	yellow	7.2 mm




Fig. 05/6

202 Intake valve stem seal
 203 Exhaust valve stem seal

Due to the different ID they are not interchangeable.

Checking and adjusting valve clearance

The valve clearance is measured between cam base circle and cup-type tappet (arrows, Fig. 05/3).

Valve clearance (in mm)

Valve	Coolant temperature	
	up to 50 °C (engine cold)	60 – 80 °C (engine warm)
Intake	0.10 – 0.20	0.15-0.25
Exhaust	0.25 – 0.35	0.30 – 0.40

If the valve clearance is too large or too small install a thicker or a thinner thrust plate (220, Rg. 05/3).

There are 23 thrust plates of varying thickness (0.025 mm increments). 15 thrust plates are available for repair sector (0.05 mm increments). The thickness dimension is stamped into thrust plate.

A storage box is available for storing thrust plates (refer to special tools). For checking and adjusting refer to maintenance jobs.

The valve clearance must be checked during maintenance service every 24 000 km (15,000 miles) and adjusted, if required.

Chain drive




Fig. 05/7

- | | |
|------------------------------|--------------------|
| 1 Crankshaft | 25 Guide rail |
| 4A Camshaft sprocket exhaust | 27 Holder |
| 4E Camshaft sprocket intake | 31 Guide rail |
| 5 Crankshaft sprocket | 32 Guide rail |
| 12 Intermediate sprocket | 33 Holder |
| 18b Idler sprocket | 35 Chain tensioner |
| 21 Single roller chain | A Check bores |
| 22 Tensioning rail | |

Camshaft sprockets (4 A and 4 E)

The camshaft sprockets have a shaft end by which they are mounted in the cylinder head.

Bearing dia. 28 mm, same as camshaft bearing.

Each camshaft is fastened to a camshaft sprocket by four screws M 6 x 25 mm (10). The hole pattern of the four screws is non-symmetrical. Therefore, they can only be screwed on in one position.

Tightening torque 12 Nm.

The bearings are supplied with oil via the hollow camshaft sprockets.

The front bore on the intake camshaft sprocket is closed with a sheet metal plug.

On the exhaust camshaft sprocket the bore is closed by the hex. socket head screw for mounting the driver for the hydraulic oil pump of the level control system.

The camshaft sprockets are of a different design due to the shaft ends.




Fig. 05/8

The camshaft assembly with camshaft sprocket is axially fixed by a collar on the shaft end of the respective camshaft sprocket running in a groove in the cylinder head.

When the two bores (2 mm dia.) in the camshaft sprockets are opposite each other (arrows) the piston of the 1st cylinder is in TDC position of the compression stroke.




Fig. 05/9

Repair note

The camshaft sprockets need not be removed for removal and installation of camshafts.

Single roller chain (21)

The single roller chain has 134 links. For repairs, a timing chain with a connecting link is available. The connecting link is riveted with the riveting tool 000 589 58 43 00 (as on diesel engines) and the rivet set 103 589 01 63 00.

Guide rail (32)

Due to the longer timing chain drive, the guide rail (32) prevents vibrations between intermediate sprocket and idler sprocket. The guide rail is snapped into bracket (33). This bracket is fastened with a pin in a bore at the bottom and at the top with a timing chain housing cover screw at the boss (arrow) of the cylinder block.




Fig. 05/10

Guide rail (31)

Guides the timing chain between the sprockets and floats on the two pins (27a) of bracket (27) and is secured by the lockrings (34). The axial clearance of the guide rail (31) is limited through the use of two spring washers (28).




Fig. 05/11

Repair note

In case of noise complaints from the area of the cylinder head front, check if spring washers (28) are installed.

Tensioning rail (22)




Fig. 05/12

Version A Engines 102.92/93/96/980
Version B Engine 102.983

The tensioning rail differs in shape and length from that of the other engines 102. They are not interchangeable.

Intermediate sprocket (12)

The intermediate sprocket floats on the shaft. The shaft is pressed into the cylinder head and closed by a plug M 18 x 1.5 mm (14) and a sealing ring (15) towards the outside.




Fig. 05/13

Repair note

The intake camshaft sprocket, the chain tensioner and the radiator shroud must be removed for removal and installation of the intermediate sprocket.

Hydraulic oil pump drive

The hydraulic oil pump for level control is mounted to the cylinder head with a separate flange. It is driven by the camshaft sprocket of the exhaust camshaft. For layout, refer to Fig. 05/15.




Fig. 05/14




Fig. 05/15

55	Cylinder head	236	Drive sleeve
66 a	Bearing cap	237	Mounting screw, drive sleeve
85	Valve cover	238	Flange
97	Valve cover gasket	241	O-ring
163 a	Camshaft sprocket, exhaust		
235 a	Driver		


Mechanically/electronically controlled gasoline injection system (CIS-E)

The construction and function of the gasoline injection system is similar to engine 102.985 except for the following modifications:

Modifications:

- Maximum engine speed cut-out is controlled by the fuel pump relay
- Fuel pump (same as models 107 and 126) with integrated suction damper
- Fuel pump package suspended on rubber rings
- System pressure increased to 5.8 bar
- Fuel distributor and airflow sensor adapted to engine
- Air enveloped injection valves
- Location of injection valves and cold-start valve modified
- CIS-E electronic control unit with air/fuel mixture adaptation by microprocessor and logic circuit
- Intake air temperature sensor on air filter
- Altitude correction capsule
- Electronic idle speed control by a single coil rotary air valve. The bypass adjusting screw was eliminated
- Throttle valve switch with idle and full load contact
- Deceleration shutoff microswitch
- O₂-sensor replacement indicator was replaced by an O₂-sensor malfunction indicator.

Input signals affecting the electronically controlled mixture correction



Components and function

Fuel pump relay (N16/3 or N16/4)

The relay is located on the right side in the component compartment.

N16/3 is used on manual transmissions and N16/4 on automatic transmissions with the following functions:

- cold start valve activation
- rpm limitation
- kickdown shutoff (N16/4 only)




Fig. 07.3/1

Cold start valve activation

Its function depends on coolant temperature and cranking speed signal. Voltage supply is via the fuel pump relay. The length of time during which the cold-start valve injects fuel is dependent on the coolant temperature. For example, at $-20\text{ }^{\circ}\text{C}$ the valve opens for 10 seconds. Above $15\text{ }^{\circ}\text{C}$ the valve remains closed.

If the engine starts before the cold-start valve completes its cycle, cold-start injection is canceled immediately.

Maximum engine speed cut-out

If the fuel pump relay receives a certain frequency signal corresponding to the maximum engine rpm, the contact between circuit 30 and 87 is interrupted and the fuel pump is turned off.

Fuel pump package

The fuel pump package is located at the left in front of the rear axle on the frame floor, seen in driving direction. The fuel pump package is suspended on rubber rings (35).




Fig. 07.312

- | | |
|---------------------|-----------------|
| 14 Fuel accumulator | M 3 Fuel pump |
| 21 Fuel filter | 35 Rubber rings |

Diaphragm pressure regulator (40)

The system pressure was increased to approx. 5.8 bar. The pressure is set by manufacturer and cannot be adjusted.




Fig. 07.3/3

- | |
|---------------------------------|
| 40 Diaphragm pressure regulator |
| 50 Supply system pressure |
| 50a Line to fuel cooler |
| 51 Fuel return flow |

Mixture preparation

The fuel requirement is adapted to the various engine load conditions by wider metering slots (29) in the metering sleeve (28). The air funnel in the air flow sensor is designed for an air-fuel mixture ratio of $\lambda = 1$.

For better mixture preparation at idle air is injected around the injection valves similar to engines 1161 117.

Note: Due to the limited space, fuel line 117 070 28 32 must be used for measuring lower chamber pressure at the pressure connection.




Fig. 07.3/4

- 27 Control plunger
- 28 Metering sleeve
- 29 Metering slot




Fig. 07.3/5

- 2 Insulating sleeve
- 3 Plastic supporting ring
- a Fuel
- b Air
- c Fuel-air mixture

Overvoltage protection relay (K1)

The relay is located in the component compartment in driving direction on the right side (K1). The wiring was correspondingly changed.




Fig. 07.3/6

Intake air temperature sensor (B17/2)

The temperature signal is transmitted to the CIS-E control unit. The resistance values are identical to the coolant temperature sensor. At low ambient temperatures a correction of the acceleration enrichment takes place.




Fig. 07.3/7

- B17/1 Intake air temperature sensor (EZL)
- B17/2 Intake air temperature sensor (CIS-E)

Coolant temperature sensor (NTC)

The coolant temperature is picked-up by a dual temperature sensor (arrow). One temperature is transmitted to the CIS-E control unit and the other to the electronic ignition control module (EZL). The nominal test values are the same for both temperature signals. Their test values correspond with the coolant temperature sensor of model 201.024.




Fig. 07.3/8

CIS-E control unit

It is located in the component compartment in driving direction on the right side (arrow).




Fig. 07.3/9

The basic control functions of start enrichment, after-start enrichment, warm-up, acceleration and full load enrichment, as well as deceleration shutoff are the same as previously, however the control values are adapted to this engine.

Cranking enrichment/after-start enrichment

During cranking, the microprocessor in the control unit recognizes the cranking speed (start of cranking above 30 rpm, end of cranking approx. 500 rpm) from rpm impulses. When the cranking speed is attained, the control unit releases the start enrichment and the after-start enrichment. Extent and duration of enrichment (current on EHA) depend on coolant temperature.

The input of the cranking signal (terminal 50) into the CIS-E control unit is eliminated.

Acceleration enrichment

It becomes effective in the warm-up stage and with the engine at operating temperature. The current to the EHA is dependent on acceleration.

Full load enrichment

Effective with throttle valve fully opened. Depending on the engine speed, the current at the EHA can vary between 5 mA (–) to 10 mA (+). Lambda control is set by the control unit (no regulation).

An idle speed contact is additionally integrated in the switch. The idle speed signal is required by the electronic ignition switching unit.

Deceleration shutoff

Changes to the deceleration shutoff are as follows:

Restart of fuel injection begins at an engine speed of 1500 rpm.

Deceleration shutoff occurs only if the engine speed exceeds 2500 rpm.

Current to the electrohydraulic actuator (EHA) is approx. 45 mA (–).

New routing of wiring harness.

(For complete wiring diagram, refer to Fig. 07.3/13).

Logic circuit

Input signals from the various sensors and switches are continuously monitored by the electronic control unit. If, for example, with the engine at operating temperature, a rapid temperature change is simulated by unplugging the coolant temperature sensor – the microprocessor in the control unit will compare this momentary temperature with the temperature in its memory. The control unit will recognize the abrupt temperature change as a short circuit, and is programmed to the fixed operating mode.

The control unit does not recognize gradual changes as malfunctions, and will continue to operate normally.

Fixed operating mode

In the event of an illogical signal received by the control unit (i. e. system malfunction, open or short circuit) the control unit will automatically revert to a Fixed Operating Mode (FOM). This means that the engine will continue to run but not at its optimum, electronically controlled performance level.

O₂-sensor

The O₂-sensor replacement indicator is now an O₂-sensor malfunction indicator. The O₂-sensor malfunction light will come on only if a malfunction is present in the O₂-sensor circuit. The O₂-sensor malfunction indicator lamp receives voltage from the CIS-E control unit. The indicator lamp lights up briefly when ignition is turned on.

Electronic idle speed control

The function of the electronic idle speed control is essentially the same as previously.

The control unit processes the following information:

- Engine speed (ignition terminal TD)
- Coolant temperature
- Idle speed signal (microswitch)
- Air flow sensor, voltage
- Voltage, altitude correction sensor
- Automatic transmission, shift lever position
- A/C compressor, cut-in signal

The function of the idle speed control system is extended by the air flow sensor voltage signal. As a result, the control unit recognizes the momentary air flow rate. In combination with the engine speed, the position of the microswitch and the coolant temperature, the activation of the idle speed air valve and thereby the idle speed will be determined.

Note: At deviating idle speed (too high or too low) the voltage signal must be checked on the air flow sensor.

Idle speed air valve

Designed as a single coil rotary actuator with a two-pin connection.

The adjusting screw for bypass air was eliminated.

The idle speed air valve has the following functions:

1. The electronic control unit supplies a specific voltage to the air valve which determines the respective valve opening and thereby the engine speed.
2. The nominal idle speed is controlled depending on temperature, between 1200 rpm at – 30 °C to 890 ± 50 rpm at + 70 °C.
3. With the ignition switched on (engine not running) the idle speed air valve is activated by a specific voltage. The port for the fixed operating mode is closed and the control port is opened.
4. If the voltage supply fails, the port for the fixed operating mode is opened automatically.




Fig. 07.3/10

- | | | | |
|----|---------------|----|-----------------|
| 84 | Spiral spring | 89 | Aperture valve |
| 85 | Shaft | 90 | Coil cap washer |
| 86 | Magnetic coil | 91 | Hollow shaft |
| 87 | Coil Jacket | | |

Rpm stabilization on engines with A/C compressor engaged

When the air conditioning system is switched on, the CIS-E control unit (terminal 19) is connected to voltage. This signal goes over a time delay relay (350 ms) to the A/C compressor control unit. The CIS-E control unit processes the signal and gives a specific signal to the idle speed air valve. The control opening in the air valve becomes larger before the A/C compressor is engaged and the idle speed deviates only slightly.

Idle speed stabilization on engines with automatic transmission

With the selector lever in a driving position, the ground connection to the starter is interrupted at terminal 50 of the starter lockout switch.

Ground is present in position P and N. The control unit processes the signal change and transmits a defined voltage signal to the idle speed air valve, so that a specific idle speed will result.





Fig. 07.3/11 Function diagram of electronic idle speed control

1	Fuel distributor	W 10	Ground, battery	bl	blue
12	Intake manifold	w 11	Ground, engine (electric wire connection)	br	brown
92	Injection valve	Y 6	Idle speed air valve	ge	yellow
93	Insulating sleeve	Y 8	Cold start valve	gn	green
B 1 1/2	Coolant temperature sensor (2-pin)	X 48	Solder terminal in wiring harness	gr	grey
N 3	CIS-E control unit (25-pin connector)	v	to overvoltage protection relay (pin 2) circuit 87	rt	red
S 27/2	Micro switch, deceleration shut off	y	to ignition control module connector (terminal 1)	sw	black
				ws	white

Idle speeds depending on transmission are shown in the following table.

Idle speeds above 70 °C coolant temperature

		Idle speed rpm
Manual transmission		890 ± 50
Automatic transmission	shift lever position "P" or "N"	890 ± 50
	driving position engaged	670 ± 50



1072-1237112

Fig. 07.3/12 Function diagram, CIS-E gasoline injection system

- | | | | | | |
|--------|--|--------|---|----|--------|
| B 2 | Air flow sensor position indicator | X 56 | Plug connection, throttle valve switch | bl | blue |
| B 11/2 | Coolant temperature sensor (2-pin) | X 60/1 | Plug connection, O ₂ -sensor heating coil | br | brown |
| B 18 | Altitude correction capsule | X 60/2 | Plug connection, O ₂ -sensor signal | ge | yellow |
| G 3/2 | O ₂ -sensor, heated | Y 1 | Electrohydraulic actuator (EHA) | gn | green |
| K 1 | Overvoltage protection relay | Y 6 | Idle speed air valve | gr | grey |
| N 3 | CIS-E control unit (25-pin connector) | | | rt | red |
| s 27/2 | Micro switch, deceleration shut off | a | to Indicator lamp, O ₂ -sensor malfunction | SW | black |
| s 29/2 | Throttle valve switch, idle and full load contacts | t | to Fuel pump relay, circuit 87 connector (terminal 2) | ws | white |
| w 10 | Ground, battery | Y | to ignition control module connector (terminal 1) | | |
| w 11 | Ground, engine (electric wire connection) | f | to ignition control module (EZL) connector (terminal 2) | | |
| X 48 | Solder terminal in wiring harness | | | | |

Altitude correction

Depending on altitude, the amount of fuel is changed based on a signal from the altitude correction capsule (B 18).

With the ignition switched on or with the engine running, the altitude correction capsule will receive a constant voltage signal (approx. 5 volts) from the control unit.




Fig.07.3/14

If the electronic control unit operates in a fixed mode, correction for altitude will not take place.







With increasing altitude, i. e. decreasing air pressure, the mixture will be adapted to the altitude by a reduction of the voltage.

Measurements are made between terminal 1 and terminal 3 of the altitude correction capsule.

Height above sea level	Barometric pressure	Voltage at altitude correction capsule, plug connected
m	mbar	volts
0	1013	4 ± 1
1000	899	3 ± 1
2000	795	2 ± 1

Checking electric components of CIS-E injection system
(after checking fuel pressures and for internal leaks)

Special tools



Conventional testers

Multimeter^{*)}

e.g. SUN DMM-5

^{*)} Available through the MBNA Standard Equipment Program

Testing overvoltage protection relay (K 1)

Switch-on ignition, test voltage from control unit plug (terminal 1) to ground.	
Battery voltage	
OK	Not OK





Fig. 07.3/15






Fig. 07.3/16

Testing coolant temperature sensor

Unplug coolant temperature sensor. Test resistance from sensor terminal to ground.	
For nominal value, refer to diagram.	
Test sensor resistance at two temperatures.	
Example:	
+ 20 °C = 2.2–2.8 kΩ	
+ 80 °C = 290-370 Ω	
OK	Not OK



Connect test cable to EHA. Set multimeter to mA. Switch on ignition. Read current value.	
<ul style="list-style-type: none"> ● Engine not running, reading approx. 50 mA. ● Engine at idle speed and operating temperature - reading fluctuates. ● Engine at idle speed, + 20 °C coolant temperature simulated with 2.5 kΩ test cable (Fig. 07.3/20). O₂-sensor plug disconnected - Reading 5 - 15 mA. 	
OK	Not OK





Fig. 07.3/17





Fig. 07.3/18



Testing acceleration enrichment and air flow sensor position indicator

Connect test cable to EHA. Set multimeter to mA. Simulate + 20 °C with 2.5 kΩ test cable (Fig. 07.3/20). Disconnect O₂-sensor plug. Start engine (increased idle speed).

Nominal value 5-1 5 mA. Increase engine speed quickly, current value should increase.

OK	Not OK
----	--------

End of test




Fig. 07.3119

Stop engine. Deflect air flow sensor plate with adjusting device from fuel quantity comparison tester until the upper edge of the air flow sensor plate is in alignment with lower edge of the cylindrical part of the air funnel. Loosen plug of air flow sensor position indicator so that the voltage can be measured at the pins (do not disconnect plug). Switch on ignition.

(Refer to Fig. 07.3/22)
Terminal 3 and terminal 1 : approx. 5 V
Terminal 2 and terminal 1 : 0.2-0.5 V

OK	Not OK
----	--------




Fig. 07.3/20

Slowly deflect air flow sensor plate.

Voltage increases continuously to approx. 5 Volts.

OK	Not OK
----	--------

Replace air flow sensor position indicator.




Fig. 07.3121





Fig. 07.3/22





Fig. 07.3/23




Fig. 07.3/24

- S 29/2 Throttle valve switch plug (idle and full load contacts)
full load/idle speed stabilization
- X 56 Throttle valve switch plug
 - 1 Idle contact (LL)
 - 2 Common
 - 3 Full-load contact (VL)

Note: Without an idle speed signal, idle speed will be irregular.





Fig. 07.3/25




Fig. 07.3/26





Fig. 07.3/27




Fig. 07.3/28







Fig. 07.3/29




Testing lambda control


Testing O₂-sensor

Note: The O₂-sensor must be tested with the engine at operating temperature.

Function test: With the engine running, deflect airflow sensor plate slightly by hand. The needle on the lambda tester must move to the lean mixture stop. If not, perform the following test:



Testing O₂-sensor heater (engine shut off)



Test and adjustment data

Static current at EHA	Engine not running, ignition "ON"		approx. 50 mA
Coolant temperature sensor	Coolant temperature	Resistance	2.2-2.8 kΩ
	+ 20 °C (basic warm-up value)	Current on EI-IA	5-15 mA
	Coolant temperature	Resistance	290-370 Ω
	+ 80 °C	Current on EHA	value fluctuating
Lambda control	Engine at idle		50 ± 10 %
Deceleration shutoff		Current on EHA	approx. 45 mA (-)
Rpm and control range	Idle speed		890 ± 50 rpm
	Max. engine speed		6800 ± 50 rpm

Fuel pressures

System pressure at idle with engine cold or at operating temperature		5.7 – 5.9 bar
Lower chamber pressure with engine at operating temp.		0.4 bar below previously measured system pressure
Lower chamber pressure at + 20 °C coolant temperature	with the vehicle at standstill, at idle speed	0.5 bar below previously measured system pressure
	Acceleration enrichment	above 3.8 bar
Decel shutoff		lower chamber pressure equal to system pressure
Return flow quantity at orifice in fuel distributor		130 – 150 cc/minute

Fuel pump

Bosch No.		0 580 254 974
Measuring instruction		with engine stopped and a voltage of min. 11.5 volts at fuel pump
Delivery capacity ¹⁾	Measuring point	Fuel line after diaphragm pressure regulator
		min. 1 liter in 40 seconds
Current draw		approx. 7.5 amps

¹⁾ For measuring delivery capacity the fuel tank should be at least half full

Model Year 1987 changes to Mechanically/electronically controlled gasoline injection system (CIS-E)

Mechanically/electronically controlled gasoline injection system (CIS-E)

Fuel pump package

The two fuel pumps are arranged in series. A diaphragm damper is integrated in the fuel pumps on the suction side.

The fuel pump package is located as before on the left side in front of the rear axle on the frame floor.






Fig. 07.3/1

- | | |
|---------------------|----------------|
| 55 Fuel filter | M3/1 Fuel pump |
| 57 Fuel accumulator | M3/2 Fuel pump |

Testing fuel pump delivery

Special tools



Testing fuel pump delivery

(see Service Microfiche, Job No. 07.3-130)

Nominal value: 1 liter minimum in 40 seconds. If this delivery quantity is not obtained determine cause by performing a pressure test.

Testing fuel pressure

- 1 Remove fuel pump package cover (Fig. 07.3/3)
- 2 Unscrew cap nut on fuel pump M 3/1. Attach connection fitting and pressure gauge 0 to 10 bar (Fig. 07.3/4)
- 3 Unplug fuel pump relay and bridge terminals 7 and 8 (circuit 30 and 87).
- 4 Reading on pressure gauge must be between 2 and 4 bar. If the pressure is below 2 bar, fuel pump M 3/1 is defective. If the pressure is above 4 bar, fuel pump M 3/2 is defective.
- 5 Disconnect pressure gauge, unscrew connection fitting and install cap nut.
- 6 Install fuel pump package cover.

Note:

This test can also be used on engines 103,116 and 117 equipped with two fuel pumps.




Fig. 07.3/3




Fig. 07.3/4

Air filter

The air filter housing is adapted to the installation conditions. It is fastened by one clip and two nuts.

The air is drawn in from outside the engine compartment via plastic scoop (arrow) and air hose (1).

The filter element is a plate-type filter.

Note: Two temperature sensors are installed in the air cleaner housing.

Repair note

To prevent damage to the air filter housing, disengage carefully rearward out of clip fastener after the two mounting nuts have been removed.




Fig. 09/1




Fig. 09/2

B 17/1 Intake air temperature sensor (EZL)
 B 17/2 Intake air temperature sensor (CIS-E)

Belt drive

Single-belt drive

Similar to engine 102.985, all the accessories are driven by a poly-V-belt.

Shock absorber (28) for the tensioning device (1) of the poly-V-belt (27) and bracket (29) were changed.

The modified shock absorber can be recognized by its circular grooves.

Length of belt \approx 1885 mm

Repair note:

In case of repairs, the shock absorber must be fastened in bore (B) of the bracket (29).




Fig. 13/1

Intake manifold, exhaust manifold

Intake manifold

The intake manifold is adapted to installation conditions and to engine. The diameter of the intake ducts (per intake valve) is approx. 26 mm. The intake ducts are fork-shaped prior to cylinder head. As a result, each intake valve has one intake duct.




Fig 14/1

Exhaust manifold

The exhaust manifold is designed as a steel pipe manifold and enters a dual pipe exhaust system. The pipes of cylinder 1 and 4, as well as of cylinder 2 and 3 are joined. The pipe diameter is approx. 42 mm.

A sheet metal gasket per cylinder is installed as an exhaust manifold seal.




Fig. 14/2

Repair note

For removal and installation of exhaust manifold remove screw (arrow) from heater return flow pipe and pull return flow pipe in direction of engine.




Fig 14/3

During assembly proceed as follows:

- 1 Insert screw for holder (on transmission bell) hand tight.
- 2 Tighten nuts for exhaust manifold on cylinder head.
- 3 Tighten screw for holder.

Catalyst

The exhaust system is equipped with two primary catalysts (Fig., 14/4) and one under floor catalyst.




Fig. 14/4

Electrical system, engine

Electronic ignition system with electronic timing adjustment (EZL)

The ignition system **corresponds** to that of model 124.030 except for the following modifications:

- The ignition control module was adapted to engine 102.983.
- Position indicator with longer cable.
- **Flywheel** or flex plate with two segments.
- An additional intake air temperature sensor is installed in the air filter.
- High voltage distributor with modified internal construction.
- New spark plug connectors.

Components of ignition system

flywheel or flex plate with segments

Two segments offset by 180° on the ring of the flex plate or flywheel are used for controlling ignition timing.




Fig. 15/1

A Segment
arrow Locating bore

Temperature sensor intake air with electronic control 25 °C




Fig. 15/2

The intake air temperature sensor has an electronic device, which retards the full load characteristic at temperatures above 25 °C.

High voltage distributor (ignition distributor)




Fig. 15/3

The high voltage distributor is now only serving the purpose of high voltage distribution. Flyweights, vacuum control unit and inductance transmitter system are no longer installed.




Fig. 15/4

The distributor cap is attached to ignition distributor by special M 6 screws. The protective cap for the interference suppression is mounted on distributor cap and fastened with two star washers.




Fig. 15/5

Interference suppression resistors: on distributor cap per connection 1 kΩ, distributor rotor 1 kΩ.

Spark plug connector




Fig. 15/6

A new spark plug connector with 1 kΩ interference suppression resistor is installed.

Note: Twist spark plug connector prior to pulling.

Reference input resistor plug (EZL, R 16/1)




Fig. 15/6a




Fig. 15/7 Wiring diagram, electronic ignition system with electronic timing adjustment (EZL)

- | | | | |
|--------|--|------|---|
| B 11/2 | Coolant temperature sensor | w 11 | Ground, engine (electric wire connection) |
| B 17/1 | Intake air temperature sensor (EZL) | x 11 | Diagnostic socket, terminal block, terminal TD to CIS-E control unit plug (terminal 13) |
| L 5 | Position indicator, flywheel/flex plate | a | to CIS-E control unit plug (terminal 13) |
| N 1/2 | Ignition control module | b | to electrical center, connector S, terminal 11 (circuit 30) |
| R 16/1 | Reference input resistor plug (EZL) | c | to electrical center, connector S, terminal 4 (circuit 15) |
| S 5/3 | High voltage distributor | d | to CIS-E control unit plug (terminal 5) |
| S 29/2 | Throttle valve switch, full load/idle speed contacts | e | to CIS-E control unit plug (terminal 21) |
| T 1 | Ignition coil | f | to electrical center, connector U, terminal 6 (circuit 15 R) |
| w 3 | Ground, front left wheelhousing (ignition coil) | | |

Removal and installation of high voltage distributor

Removal/installation is as before. Pay attention to the following items:

- 1 Ignition distributor cap is fastened with screws.
- 2 Adjustment of ignition timing is no longer required. The ignition timing is determined by the switching unit.

Removal and installation of spark plug connectors and spark plugs

Note

Clean ignition cable cover, loosen the 3 screws and remove.




Fig. 15/8

Loosen spark plug connectors by twisting to the right and left and pulling off.




Fig. 15/9

Testing EZL electronic ignition system

Test values

Voltages

	Coil terminal 15 (terminal 5 diagnostic socket)	Battery voltage
Ignition on (engine off)	between coil terminal 15 and 1 (terminal 5 and 4 diagnostic socket)	0 v
	4-pole round plug (ignition control module)	Terminal 15 and terminal 31 Terminal 16 and terminal 31

Resistances (test data at 0 °C to 100 °C)

Ignition coil	Primary (terminal 1 and 15)	0.3-0.6 Ω
	Secondary (terminal 1 and 4)	7-13 kΩ
Position sensor		680-1 200 Ω
Reference input resistor (EZL)		750 Ω

Dwell angle

at cranking speed		1 0-54 % or 9-49 °
at 4000 rpm		30-60 % or 27-54 °

Ignition timing (firing point)

at cranking speed		TDC ± 2 °
at idle		below 20 °
at 4000 rpm	without vacuum, intake air temperature sensor plug pulled off	18-22 °
at 4000 rpm	with vacuum, intake air temperature sensor plug pulled off	29-33 °

Conventional testers

Multimeter ¹⁾		SUN DMM-5
Engine tester ¹⁾		SUN EMT-I 019, Master 3, MCM-2110
Tachometer ¹⁾		All-Test 361 O-MB

¹⁾ Available through the MBNA Standard Equipment Program

For test procedure see engine 103 with the following exception.

Disconnect intake air temperature sensor plug (arrow) when checking ignition timing at 4000 rpm.




Fig. 15/10

B 17/1 Intake air temperature sensor (EZL)

Spark plugs (with conical seat)

BERU	BOSCH	CHAMPION
Designation	Designation	Designation
Electrode gap	Electrode gap	Electrode gap
Part number	Part number	Part number
14 K- 6 DU	H 6 DC	s7 YC
0.8	0.8	0.8
102 159 1203	102 159 1203	102 159 1203

Engine lubrication

Lubrication circuit




Fig. 18/1

- | | | |
|--|-----------------------------------|--|
| 1 Oil strainer | 6 Bypass valve oil filter element | 13 Camshaft - intake |
| 2 Oil pump | 7 Oil-to-air cooler | 14 Intermediate sprocket |
| 3 Oil pressure relief valve | 9 Chain tensioner | 15 Idler sprocket |
| 4 Thermostat 110 °C
(in oil filter housing) | 10 Camshaft sprocket - exhaust | 16 Oil pressure gauge (instrument cluster) |
| 5 Oil filter element | 11 Camshaft - exhaust | 17 Oil temperature gauge |
| | 12 Camshaft sprocket - intake | 18 Oil pressure sensor |

Oil filling capacities in liters (for approved engine oils, refer to Specifications for service products)

Total quantity for initial filling	5.5
Quantity at oil and filter change	5.0
Oil pan max./min	4.8/2.8

Oil filter

A thermostat (332 b, Fig. 18/2) in the oil filter controls the oil flow through the oil-to-air cooler. Opening begins at 110 °C oil temperature. Fully opened at 125 °C oil temperature.




Fig. 18/2

- | | |
|------------------------|--|
| 320 Oil filter housing | 334 Plug |
| 320a Threaded bushing | 335 Seal ring |
| 321 Return tube | 336 Cover |
| 323 Valve cone | 337 Seal ring |
| 324 Compression spring | 338 O-ring |
| 325 Spring retainer | 339 Center bolt |
| 326 Retaining ring | A Connection to oil-to-air cooler |
| 327 Valve cone | B Connection from oil-to-air cooler |
| 328 Valve seat ring | a Supply from oil pump |
| 329 Compression spring | b Return flow to oil pan |
| 331 Oil filter element | c Uncleaned oil to main oil duct |
| 331 a Rubber seal | d Cleaned oil to main oil duct |
| 331 b Rubber seal | f Connection for oil temperature gauge |
| 332 a Slide | g Connection for oil pressure gauge |
| 332 b Thermostat | |
| 333 Compression spring | |
- 1) Filter element bypass valve
2) Return flow check valve

Note:

The oil filter is sectioned in different planes to show its function properly. Therefore, the connections for hoses and sensors are not always shown in the correct position.

Even with the thermostat fully opened, a given oil quantity will still flow directly to oil filter element.

The oil cooler lines are screwed directly into oil filter housing.

Cup-type tappet and cam lubrication (Fig. 18/1)

The cup-type tappet and cams are lubricated in an oil sump (sump lubrication). The oil sump is filled with the oil emerging laterally on camshaft bearings (leak oil).

Oil temperature gauge

For instrument refer to Group 54.

The oil temperature is picked up on the oil filter by a temperature sensor (67).




Fig. 18/3

The operating temperature of the oil is 80-120 °C.

An increase up to max. 150 °C is permitted. If this value is exceeded, check oil level first. Level should not be above max. mark.

Engine cooling

Coolant pump

To provide sufficient clearance for the cylinder head, the long feed connection (B, arrow) has been moved downward.




Fig. 20/1

A Coolant pump
Engine 102.985

B Coolant pump
Engine 102.983

Repair note

Coolant pumps are not interchangeable.

Thermostat housing and thermostat

The thermostat housing is sealed with an O-ring to the coolant return flow pipe in the cylinder head (109, Fig.01/18) and is fastened by 4 screws.

Tightening torque 21 Nm.

The following temperature switches or temperature sensors are screwed into the thermostat housing:

Temperature sensor for coolant temperature gauge (B 13).




Fig. 20/2

2-pin temperature sensor for CIS-E injection and EZL ignition system (B 1 1/2).

100 °C temperature switch for fan clutch (S 25/1).

Thermovacuum valve for fuel evaporation system (38).

Temperature switch for auxiliary fan 105 °C and A/C compressor cutout at 115 °C (S 25/5).

The thermostat housing cover is made of plastic (arrow). The thermostat is the same as for the other 102 engines.

Fan clutch

Function and layout of fan clutch are the same as for fan clutch of the engine 102.985.

Diameter of the **5-blade** fan is 430 mm.

Repair note

The fan cannot be interchanged with fan of other engines 102 in model 201.

Radiator

Light-alloy cross flow radiator (block depth 42 mm), with screwed on light-alloy oil-to-air cooler.

Engine mounts

All components of engine mounts are maintenance-free.

The right and left front engine mounts are the same (engine 102.985 has right and left different mounts). The rear engine mount is identical with model 201.024 with engine 102.985.

Throttle control

The throttle position is controlled by a Bowden cable (30) connecting the accelerator pedal to the engine.




Fig. 30/1

- | | |
|----------------------|------------------|
| 30 Bowden cable | 34 Bearing |
| 33 Accelerator pedal | 35 Return spring |

The length of the connecting rod to the throttle valve housing is 82 ± 2 mm (measured from center of ball joint to center of ball joint).




Fig. 30/3




Fig. 30/2