







05 Engine timing, valves

	Job No.
Camshaft and valves	
Checking and replacement of hydraulic valve clearance compensating elements	05—211
Checking camshaft timing	215
Removal and installation of camshaft	220
Removal and installation of valve springs	250
Checking valve springs	260
Replacing valve stem seals	270
Checking and machining valves.	280
Replacing valve seat rings	290
Machining valve seats	291
Timing chain, chain tensioner, tensioning and slide rails	
Removal and installation of chain tensioner	310
Replacing timing chain	320
Removal and installation of tensioning rail	330
Removal and installation of slide rails	341
A. Removal and installation of slide rail (220) in cylinder head	
B. Removal and installation of guide rail (218)	
Drive for hydraulic oil pump	
Removal and installation of drive for hydraulic oil pump.	437

05-211 Checking and replacement of hydraulic valve clearance compensating elements

Tightening torques	Nm
Bolts for cylinder head cover	10
Bolt for camshaft timing gear	45
Bolts for camshaft bearing caps	25

Special tools

Torque wrench, double arm, 3/8" square, 8-32 Nm		001 589 51 21 00
Torque wrench with plug-in ratchet 1/2" square, 25-1 30 Nm		001589662100
Measuring bridge for residual stroke		601 589 08 21 00
Vacuum lifter for valve tappet		601589053300


Note

Store valve tappet in upright position only (open end up).

Install removed valve tappets again at the same spot.

The basic position of valve tappets cannot be corrected.

In the event of complaints about noise, perform the following test jobs:



185 Camshaft
203 Valve tappet

1053-11606


Checking

- 1 Run engine for approx. 5 minutes at 3000/min.
- 2 Remove cylinder head cover.
- 3 Set cam of respective valve tappet on base circle (cam tip should point upwards).

- 4 Use a mandrel to push against valve tappet or try to move valve tappet manually.


If, compared with others, the valve tappet drops quickly, or in the event of play in relation to base circle of cam, perform jobs item 6 and starting item 8.

If a valve tappet has play, or if the sinking time is too short, check basic position (item 5–7).



- 5 Measure and write down dimension "X" (cylinder head parting surface to valve tappet). For this purpose, place measuring bridge over valve tappet about to be checked on cylinder head parting surface.


Note: If required, measure dimension "X" on all valve tappets.




- 6 Remove fan and fan cover.
- 7 Remove camshaft (05-220).
- 8 Measure dimension "Y" (cylinder head parting surface to valve tappet).

The difference between dimension "X" and "Y" is the initial stroke \triangleq installation position.


Nominal value: Value when new 0.25-1 .6 mm,
value with used engine 0.25-2.5 mm.



9 If valve tappet sinks quickly or if the nominal dimension is not attained or exceeded, lift out valve tappet by means of vacuum lifter.




10 Measure dimension "L" on valve tappet and write down.




11 Measure dimension "L 2" on valve tappet.

Dimension "L 1" (difference between L and L 2) should be 18-19 mm.



12 If dimension "L 1" is higher or lower, remove guide sleeve. For this purpose, pull guide sleeve (g) out of valve tappet (203) by means of rotary movements with pliers. Do not damage guide sleeve.




- 203 Valve tappet
 a Thrust pin with ball and cage
 b Circlip
 c Compression spring
 g Guide sleeve

13 Pull thrust bolt (a) out of guide sleeve (g) and remove compression spring (c).


14 Blow out all components with compressed air.

Blow through valve tappet at oil feed bore (arrow).



105-26838

15 Remove circlip (b) from guide sleeve (g), slightly rebend at edges (arrows) and mount again on guide sleeve.




1054-11852

16 Assemble guide sleeve (g), compression spring (c) and thrust pin (a) in correct sequence.

17 Fill thrust pin with engine oil. Press on ball valve with a suitable pin and vent work chamber by pumping movements of thrust pin, close ball valve and add oil, if required. Then, no more oil should flow out at ball valve under slight pressure.

If oil flows out, renew complete valve tappet.



105-26931


18 Fill valve tappet (203) with engine oil and install vented thrust pin with guide sleeve into valve tappet.

Push guide sleeve into valve tappet until circlip engages.

19 Check dimension "L 1", refer to item 9 and 10.

20 Check oil supply in cylinder head. For this purpose, unscrew closing plug of oil duct on cylinder head rear.

Blow with compressed air into oil duct, while checking outlet bore on seat for valve tappet for passage.



21 Lubricate valve tappet and install, pay attention to sequence.

22 Install camshaft (05–220).

23 Install cylinder head cover.

24 Install fan and fan cover.

25 Run engine at 3000/min.

05-215 Checking camshaft timing

Timing at 2 mm valve lift

Engine	Camshaft code number ¹⁾	Camshaft opens after TDC	Intake valve closes after BDC	Exhaust valve opens before BDC	closes before TDC
601	05	with new timing chain			
		11°	17°	28°	15°
		with used timing chain (after approx. 20 000 km)			
		12°	18°	27°	14°

¹⁾ The camshaft code number is stamped into collar adjacent to TDC notch.

Tightening torque


Nm

Bolts for cylinder head cover

10

Special tools

Dial gauge holder



363 589 02 21 00

Box-end wrench element, open 14 mm, 1/4" drive for coupling nut on injection line



000589 77 0300

Conventional tool

Dial gauge A 1 DIN 878

e. g. Mahr, D-7300 Esslingen
Order No. 810


Note

During assembly jobs alignment of marks (arrows) in ignition TDC position of 1st cylinder is adequate.

In special cases, e. g. in the event of complaints about output, perform the following checkup with regard to begin of opening at intake valve of 1st cylinder.

Timing is measured at 2 mm tappet travel.

Corrections are not possible at the moment.




Checking

- 1 Remove cylinder head cover.
- 2 Remove injection nozzles (07.1-230).
- 3 Turn crankshaft until cam tip of 2nd cam is pointing upwards.

Attention!

Do not rotate engine on screw of camshaft timing gear. Do not rotate engine in reverse while measuring, since this would result in considerable measuring faults.

- 4 Tighten dial gauge holder on cylinder head (above 1st cylinder intake valve).
- 5 Position dial gauge with extension and fasten in such a manner that the sensor pin is seated on valve tappet (arrow) under a preload of 3 mm (small needle of dial gauge).



Turn dial of dial gauge until large needle points to "0".

Attention!

Sensor pin of dial gauge should be seated accurately vertical on valve tappet.

6 Continue turning crankshaft in direction of rotation of engine until small needle of dial gauge has moved back by 2 mm (valve lift) to 1 mm.

In this position, the value on balancing disk should be the same as the specified value “intake valve opens”.

7 Install injection nozzles (07 I-230).

8 Install cylinder head cover.

05-220 Removal and installation of camshaft

Timing at 2 mm valve lift

Engine	Camshaft code number ¹⁾	Intake valve		Exhaust valve		
		open after TDC	closes after BDC	opens before BDC	closes before TDC	
601	05	with new timing chain				
		11°	17°	28°	15°	
		with used timing chain (after approx. 20 000 km)				
		12°	18°	27°	14°	

¹⁾ The camshaft code number is stamped into collar adjacent to TDC notch.

Data

Permissible runout of center bearing journal and of camshaft timing gear seat when mounting camshaft in outer bearing points	Camshaft code number	05
	Camshaft timing gear seat 2nd bearing point	0.020
	3rd bearing point	0.030
		0.025
Scleroscope hardness of cams	when new	64-75
	limit value	
Diameter of camshaft bearing journals		30,944–30,950

Tightening torques

	Nm
Bolts for cylinder head cover	10
Bolt for camshaft timing gear on camshaft	45
Bolts for camshaft bearing caps	25


Special tools

Torque wrench with plug-in ratchet, 1/2" square, 25-1 30 Nm




001 589 66 21 00

Torque wrench, double arm, 3/8" square, 8-32 Nm



001 589 51 21 00

Vacuum lifter for valve tappet



601 589 05 33 00


Note

The camshaft is a chill casting and mounted in five bearings.


The diameter (D) of all five bearing points is 31 .0 mm.

Groove (A) serves to locate the camshaft axially by means of a circlip inserted in cylinder head.

A cyl. pin on collar (B) serves to locate the camshaft timing gear.



The code number is stamped into flange adjacent to TDC notch (arrow).



TDC mark (arrow) and code number

105-26837

Removal

- 1 Remove cylinder head cover.
- 2 Set crankshaft to ignition TDC of 1st cylinder.

Attention!

Do not rotate engine on fastening screw of camshaft timing gear.


Do not rotate engine in reverse.

TDC mark on pulley




103-25927

3 Remove chain tensioner (244) (05-340).




4 Mark camshaft timing gear and timing chain in relation to each other.



5 Remove camshaft timing gear.


To loosen screws, apply counterhold on camshaft with a mandrel.



6 On vehicles with level control, the camshaft timing gear and the driver sleeve are fastened with a hex socket screw. Remove driver sleeve. For this purpose, unscrew pressure oil pump and put aside with lines connected.


7 Uniformly loosen all camshaft bearing screws and remove camshaft bearing caps.

Note: To prevent tilting of camshaft under influence of spring-loaded valve tappets, loosen camshaft bearing screws and unscrew uniformly.



8 Remove camshaft in upward direction.

- 70 Cylinder head
- 81 Camshaft bearing bracket
- 185 Camshaft
- 186 Circlip for axial locating
- 187 Cyl. pin
- 188 Camshaft timing gear
- 189 Washer
- 190 Screw M 10 x 50




1054 -11481

9 Remove circlip for axial locating (186) camshaft longitudinal alignment and check for condition.

10 Pull out valve tappet by means of vacuum lifter 601 589 05 33 00.

11 Check valve tappet for condition (visual checkup) and renew, if required.

Note: Install valve tappets at the same spot where they were installed before.



105-26924


Installation

Note: If a new camshaft has been installed or if the cylinder head has been machined, check camshaft for easy operation.

12 Insert circlip for axial locating (arrow) in cylinder head.

13 Lubricate camshaft and place into cylinder head (without valve tappets).

14 Position camshaft bearing cap and tighten uniformly to 25 Nm. Pay attention to identification of bearing caps.




105-26316

15 When checking for easy operation, the camshaft can be rotated by means of a hex. socket screw M 10 x 30, which is screwed in through camshaft timing gear instead of fastening screw.

If the camshaft can be rotated with an effort only, proceed as follows:

01 Hex. socket screw M 10 x 30



Loosen camshaft bearing caps individually. Then turn camshaft as required.


Repeat until tight bearing point has been found.

Remove camshaft and measure respective bearing point. Nominal 0.050-0.81 mm.

Check camshaft for runout.

16 Lubricate valve tappets and insert. Pay attention to sequence.

17 Lubricate camshaft and place into cylinder head, pay attention to circlip (186).



1054 -11481


18 Install camshaft bearing caps.

Note: Be sure to tighten camshaft bearing caps uniformly, so that the camshaft is not loaded on one side only under influence of valve tappet counter-pressure.

19 Mount camshaft timing gear. Pay attention to color marks.


Tighten fastening screw for camshaft timing gear to 45 Nm. For this purpose, apply counterhold to camshaft timing gear by means of a screwdriver or *steel* pin.

20 Install chain tensioner.



21 On vehicles with level control, mount pressure oil pump and driver.








22 Set engine to ignition TDC of 1st cylinder and check marks (arrows).



23 Mount cylinder head cover.


24 Run engine, check for leaks.

05-250 Removal and installation of valve springs

Tightening torques	N m
Bolts for cylinder head cover	10
Screw for camshaft timing gear	45
Screws for camshaft bearing caps	25
Special tools	
Torque wrench, double arm, 3/8" square, 8-32 Nm	 11004-8208 001 589 51 21 00
Torque wrench with plug-in ratchet, 1/2" square, 25-130 Nm	 11004-10056 001 589 66 21 00
Vacuum lifter for valve tappets	 11004-11748 601 589 05 33 00
Supporting bridge for valve spring depressor	 11004-11742 601 589 02 59 00
Valve spring depressor for valve springs	 11004-11776 601 589 02 61 00
Assembly board for clamping cylinder head	 11004-11741 601 589 01 59 00
Magnetic lifter for valve cone halves	 11004-6202 116 589 06 63 00


Valve arrangement intake side

- 70 Cylinder head
- 73 Valve seat ring intake
- 75 Valve guide intake
- 77a Oil duct
- 78 Core hole cap
- 81 Camshaft bearing bracket
- 84 Hex. screw M 8 x 45
- 84a Washer
- 185 Camshaft
- 195 intake valve
- 197 Thrust ring
- 197a Locking ring
- 198 Valve spring
- 200 Valve stem seal intake
- 201 Valve spring retainer
- 202 Valve key
- 203 Valve tappet



Valve arrangement exhaust side

- 70 Cylinder head
- 74 Valve seat ring exhaust
- 76 Valve guide exhaust
- 77a Oil duct
- 81 Camshaft bearing bracket
- 84 Hex. screw M 8 x 45
- 84a Washer
- 185 Camshaft
- 196 Exhaust valve
- 197 Thrust ring
- 197a Locking ring
- 198 Valve spring
- 199 Valve stem seal exhaust
- 201 Valve spring retainer
- 202 Valve key
- 203 Valve tappet



Note

Each valve has a single progressively acting valve spring (198).

For this reason, install spring only with color marks below.

Color marks:
yellow/green or purple/green

A thrust ring (197) inserted under valve springs is supported at cylinder head via torsion lock naps.


Similar to all engines, the counterbearing of the valve springs in upward direction are in the shape of valve spring retainers (201), which are fastened to the valves by means of valve cone halves (202).

With cylinder head removed, the valves can be removed as follows:

Clamp cylinder head with 4 cylinder head screws on assembly board 601 589 01 59 00.

Fasten supporting bridge 601 589 02 59 00 to cylinder head and remove valve springs by means of valve spring compressor and magnetic lifter.

Note: Install valve tappets again at the same spot from which they were removed before.



105-28928

Removal

- 1 Remove camshaft (05-220).
- 2 Remove chain tensioner (05-310).
- 3 Remove fan and fan cover.
- 4 Lift out valve tappets with vacuum lifter.
- 5 Set piston of respective cylinder to ignition TDC.

Note: For rotating engine, lift timing chain so that chain cannot be pulled in downward direction.


The pistons are in TDC position when the following marks are under TDC indicator (arrow).



103-25927

Mark	Piston at TDC
TDC	1 and 4
180° (notch)	2 and 3

6 Fasten supporting bridge for valve spring depressor on cylinder head.



7 Push valve spring retainer down by means of valve spring depressor.

8 Remove valve cone halves with magnetic lifter.

9 Remove valve springs and valve spring retainers.

10 Check valve spring (05--260).

Installation

11 Install valve spring with color dots in downward position.

12 Lubricate valve tappets and install, pay attention to sequence.

13 Install camshaft (05--220).

14 Install chain tensioner (05--310).

15 Mount cylinder head cover.

16 Install fan and fan cover.


05--260 Checking valve springs

Valve spring data

Part No.	Color code	OD mm	Wire dia. mm	Length unloaded mm	Spring force length	with preloaded when new N	limit value N
601 053 01 20	yellow/green or purple/green	33.2	4.25	50.8	27	720-770	648

Checking

- 1 Check valve springs with a valve spring tester or a spring test scale.
- 2 Check spring force at specified length.
- 3 If less than limit value, renew valve springs.











R 05/6385

05-270 Replacing valve stem seals

Tightening torques	NM
Bolts for cylinder head cover	10
Screw for camshaft timing gear	45
Screws for camshaft bearing caps	25

Special tools

Torque wrench, double arm, 3/8" square, 8-32 Nm		001 589 51 21 00
Torque wrench with plug-in ratchet 1/2" square, 25-1 30 Nm		001 589 66 21 00
Vacuum lifter for valve tappets		601 589 05 33 00
Support bridge for valve spring depressor		601 589 02 59 00
Valve spring depressor for valve springs		601 589 02 61 00
Magnetic lifter for valve cone halves		116589066300
Assembly mandrel for valve stem seal intake and exhaust		601 589024390
Valve sealing pliers		000 589 53 37 00

Note


The valve stem seals are supplied as a repair kit.

Different valve stem seals are installed during series production, refer to drawings.

All versions are made of the same elastomere material.


ID's are different according to valve stems.

199 Valve stem seal exhaust
200 Valve stem seal intake



Another version is externally the same for intake or exhaust valves. They differ at ID and on wire rings, which are phosphated (black) on the versions named above and high-polish galvanized (yellow) at exhaust valve.

Valve stem seal




Renewing

- 1 Remove valve springs (05-250).
- 2 Pull off valve stem seals with pliers 000 589 53 37 00.


Attention!

Do not damage valve stem and valve guide.



3 Deburr valve stem on groove (arrow).


4 Renew dented valve cone halves, spring retainers and thrust rings.



105-13971

5 Lubricate valve stem seal and press on with assembly mandrel 601 589 02 43 00.

For this purpose, be sure to place an assembly sleeve (included in repair kit) on valve stem.



105-26821

6 Install valve springs (05-250).

05—280 Checking and machining valves

Data

Engine	Valve disk dia.	Height "h" of valve disk when new limit value	Adjusting angle „α" for machining valve	Valve stem dia. D1	Valve seat plating	Sodium charge	Valve length L
--------	-----------------	---	---	--------------------	--------------------	---------------	----------------

Intake valve

601	37.90	0.5-0.7		45° + 15'	7.970	with	without	106.5
	38.10				7.955			106.3

Exhaust valve

601	34.90	0,5—0.6		45° + 15'	8.960	with	without	106.5
	35.10				8.945			106.3

Width of valve seat

Intake 2.5

Exhaust 3.5

Permissible runout on valve stem and valve seat max.

0.03

Conventional tools


Valve cone grinding machine
or
valve cone machining tool

e. g. Krupp, D-5309 Meckenheim
Model VS

e. g. Hunger, D-6000 München 70
Type VKDR 1, order No. 203.00.200

Identification on stem end


Engine	Intake valve	Exhaust valve
601	E 601 02	A 601 02




Checking and machining

- 1 Clean valves and check visually.

Renew valves with burnt valve disk, with insufficient height "h" of valve disk and with worn or scored valve stem.



- 2 Measure runout on valve stem. If runout exceeds 0.03 mm, renew valve.




- 3 Machine valve seat.

Pay attention to operating instructions of machining unit and adjusting angle $45^\circ + 15'$.

- 4 Measure runout on valve seat and height "h" of valve disk.


Renew valve, if limit values are not attained.




05—290 Replacing valve seat rings

Data

	Intake	Exhaust
Overlap of valve seat rings in cylinder head	0.068-0. 100	
D 2	Normal dimension	$\frac{40 .000}{40.016}$
	Repair stage max. up to	$\frac{37 .000}{37.016}$
D	Normal dimension	$\frac{40.100}{40.084}$
	Roughing dimension Repair stage	$\frac{37.100}{37.084}$
D 1	$\frac{33.400}{33.600}$	$\frac{30.400}{30.600}$
	Normal dimension and repair stages	$\frac{6.97}{7.00}$
t	9.35	9.25
	2.37	2.44
t l	2.25	2.25



Special tools

Check plug 8 mm dia. for intake valve guide		102 589 00 23 00
Check plug 9 mm dia. for exhaust valve guide		117 589 03 23 00

Conventional tools

Cylinder head clamping device	e. g. Hunger, D-8000 Miinchen 70 Order No. 221.60.000
Ring seat turning tool, size 2	e. g. Hunger, D-8000 Miinchen 70 Order No. 220.03.110
Valve seat machining tool, type VDSNL 1/45/30	e. g. Hunger, D-8000 Miinchen 70 Order No. 236.03.308
Test set for valves	e. g. Hunger, D-8000 Miinchen 70 Order No. 2 16.93.300
Internal measuring instrument (measuring range 25-60 mm)	e. g. Mahr, D-7300 Esslingen Order No. 844
External micrometer (measuring range 25-50 mm)	e. g. Mahr, D-7300 Esslingen Order No. 40 S

Note

For all valve seat ring versions each spare part is a repair **valve** seat ring with a larger OD.

Renewing

1 Unscrew old valve seat ring with ring seat turning tool.

Pay attention to operating instructions of turning tool.

2 Check valve guides and renew, if required (05-285).



3 Measure basic bore D 1.

A new normal dimension valve seat ring can be used if the specified overlap is available.

If the minimum overlap is not attained, machine basic bore for valve seat ring.


4 Machine basic bore D 1 with ring seat turning tool until the bore is just clean.

5 Measure machined basic bore.

6 Machine repair stage valve seat ring in such a manner that the specified overlap is obtained.


7 Heat cylinder head in water bath to approx. 80 °C.

8 Undercool valve seat ring with liquid nitrogen.




9 Knock in valve seat ring with a suitable guide mandrel.

10 Machine valve seats (05-291).



Data


	Intake	Exhaust
Valve seat width b		
Valve seat angle α	45°	
Correction angle at top β	15°	
Correction angle bottom γ	60°	
Permissible out-of-true of valve seat	0.05	



Valve distance to cylinder head parting surface

Minimum distance a with new valves and new valve seats	Intake/Exhaust	-0.1 to -0.5
Max. distance a with refinished valve seats and reground valves	Intake	
	Exhaust	

The max. distance is reduced by the same dimension by which the cylinder head parting surface has been refinished.



Valve disk dia.	Intake	37.90
		38.10
	Exhaust	34.90
		35.10

Special tools

Check plug 8 mm dia. for intake valve guide		102589002300
Check plug 9 mm dia. for exhaust valve guide		117589032300


Conventional tools

Cylinder head clamping device	e.g. Hunger, D-8000 Miinchen 70 Order No. 221.60.000
Valve seat machining tool, type VDSNL 1/45/30	e. g. Hunger, D-8000 Miinchen 70 Order No. 236.03.308
Test set for valve seats	e. g. Hunger, D-8000 Miinchen 70 Order No. 216.93.300
60° correction bit No. 13 for correction angle, bottom	e. g. Hunger, D-8000 Miinchen 70 Order No. 216.64.622

Note


Clamp cylinder head into clamping device for disassembly and machining.

Machine valve seats with valve seat machining tool, with valve seat grinding machine or with valve seat milling cutter.



Machining valve seats


- 1 Check valve guides and renew, if required.



2 Machine valve seat ($45^{\circ} 15'$) (refer to operating instructions of tool manufacturer).


Attention!

Loosen pilot only after runout of valve seat has been checked (item 3).




3 Check runout of valve seat.

For this purpose, slip fitted sleeve (19) with dial gauge holder (20) and dial gauge on pilot (5).




- 5 Pilot
- 18 Dial gauge
- 19 Fitted sleeve
- 20 Dial gauge holder

4 Measure valve seat width (b) and, if required, correct at top (β) with 15° and below (γ) with 60° .



5 Insert valves and measure distance a.

If required, renew valve seat ring (05-290).



05-310 Removal and installation of chain tensioner

Tightening torques	Nm
Chain tensioner in cylinder head	80
Closing plug for chain tensioner	60

Note

Install chain tensioner in filled condition on principle.


Suitably, completely renew chain tensioner complained about.

The hydraulic chain tensioner is supplied with pressure oil through an oil duct in cylinder head.

Check valve (227 and 228) and pressure limiting valve (227 and 231), together with compression spring (230), will keep the contact pressure of thrust pin (233) on tensioning rail approximately constant, independent of engine oil pressure.


The filling pin (233a) contributes to faster venting when filling in oil.

225 Closing plug	233 Thrust pin
226 Aluminum seal A 25 x 30	233a Filling member
227 Ball dia. 5 mm	234 Compression spring
228 Ball guide	235 Housing
229 Compression spring	236 Circlip B 16
230 Compression spring	a Feed bore from cylinder head
231 Valve disk	b To oil pan
232 O-ring	



Removal

- 1 Unscrew chain tensioner (224).




Installation

- 2 Fill chain tensioner. For this purpose, set chain tensioner with thrust pin in downward direction into engine oil SAE 10, with the oil extending over flange on hexagon. Press thrust bolt 7-10 times slowly down against stop with the assistance of a press or a column-type drill press.

Upon filling, compression of chain tensioner should be possible very slowly and uniformly only, and under considerable force.

- 3 Install chain tensioner with new sealing ring.

Thrust pin of chain tensioner should rest against lug of tensioning rail.






215 Tensioning rail
224 Chain tensioner

1053-11557

05-320 Replacing timing chain

Tightening torques	Nm
Bolts for cylinder head cover	10
Coupling nuts for injection lines (reference value)	1 O-20
Injection nozzles in prechambers	70 + 10

Special tools

Pressing-on tool	 11004-11596	000 589 57 43 00
Torque wrench, double arm, 3/8" square, 8-32 Nm	 11004-61206	001 589 51 21 00
Box-end wrench element, open, 14 mm, 1/4" drive for coupling nut on injection line	 11004-1052011	000 589 77 03 00

Note

A timing chain with connecting link is available for repairs.

If only an endless timing chain is available, the chain can be opened prior to installation (refer to item 3).

During an engine overhaul, an endless timing chain must be installed on principle.

Check sprockets for score marks and pitting.

Replacement part (repair timing chain with connecting link)


Designation	Part No.
Bushing chain with connecting link	001 997 16 94
Connecting link	000997 11 98

Repair timing chain

The connecting link is held in place by a locking spring.

The outer flanges are dyed blue.

The outer flange of connecting link is pressed on by means of pressing-on tool 000 589 57 43 00.



Connecting link with locking spring

105 - 25310

Renewing

- 1 Remove injection nozzles (07.1-230).
- 2 Remove cylinder head cover.
- 3 Remove chain tensioner.
- 4 Remove fan and fan cover.
- 5 Cover chain box with a cleaning rag and cut through both chain bolts on one link of timing chain by means of a grinding wheel.
- 6 Connect new timing chain with connecting link to old timing chain, while pushing out opened link (Fig. item 6).
- 7 Slowly rotate crankshaft in rotating direction of engine, while simultaneously pulling up the old timing chain until the connecting link comes to rest against uppermost point of camshaft timing gear.


Attention!

Timing chain should remain in mesh while rotating camshaft and crankshaft timing gear.

- 8 Take off old timing chain and connect ends of new timing chain with a connecting link.

For this purpose, secure chain ends with wire on camshaft timing gear.


- 9 Insert connecting link from the rear into timing chain (arrow).



Shown on engine 615


105-22430

10 Put separately enclosed outer flange of connecting link (with punched in IWIS identification) into pressing-on tool (arrow). The outer flange is held magnetically.



105-22429


11 Place pressing-on tool on connecting link and press on flange up to stop, while holding pressing-on tool on vertical lever.



105 - 27254

12 Force locking spring in opposite direction of engine rotation into grooves of chain pins (arrow).

13 Install chain tensioner.




105-22432

14 Rotate crankshaft and check adjusting mark in TDC position of engine.

Note: If the adjusting mark is not in order, check timing of crankshaft (05-215) and timing of injection pump (07.1-I 11).

15 Install *cylinder* head cover.


16 Install fan and fan cover.



105-25680

Note

The plastic coating of tensioning rail is not exchangeable.



- | | |
|--------------------------|-----------------------|
| 18 Injection timer | 220 Slide rail |
| 156 Sprocket | 224 Chain tensioner |
| 188 Camshaft timing gear | 244 Oil pump sprocket |
| 215 Tensioning rail | 262 Tensioning clamp |
| 218 Slide rail | |

Removal

- 1 Remove cylinder head (01-415).
- 2 Remove timing housing cover (01-210).
- 3 Remove tensioning rail from bearing bolts.





Installation

- 4 Place tensioning rail on bearing bolt.
- 5 Install timing housing cover (01-210).
- 6 Install cylinder head (01-415).
- 7 Run engine and check for leaks.

05-341 Removal and installation of slide rails

Tightening torques	Nm
Cylinder head cover	10
Screw for camshaft timing gear	45


Special tools

Impact puller for bearing bolt (basic unit)		116589203300
Threaded bolt M 6, 50 mm long for impact puller		116589013400
Torque wrench, double arm, 3/8" square, 8-32 Nm		001 589 51 21 00
Torque wrench with plug-in ratchet, 1/2" square, 25-130 Nm		001 589 66 21 00


Note

Remove timing housing cover for removal and installation of slide rail (218).

18 Injection timer	220 Slide rail
156 Sprocket	224 Chain tensioner
166 Camshaft timing gear	244 Oil pump sprocket
215 Tensioning rail	262 Tensioning clamp
218 Slide rail	




The longer bearing bolt (221), in cylinder head at top, serves for supporting slide rail as well as for spring tensioning lever of V-belt tensioning device.



A. Removal and installation of slide rail (220) in cylinder head

Removal


1 Slacken V-belt and remove. For this purpose, unscrew collar nut (378). Insert a mandrel into spring tensioning lever (374) and relieve hex. screw (375) against force of draw spring (380) until screw can be pushed back in direction of intake manifold. Release spring tensioning lever.




2 Unscrew screw (372) and remove holder (373) as well as spring tensioning lever (374).

3 Remove cylinder head cover.


4 Mark timing chain and camshaft timing gear in relation to each other.



5 Unscrew camshaft timing gear and remove. For loosening hex. screw, apply counterhold to camshaft with a screwdriver or mandrel.



- 6 Knock out both bearing bolts with impact puller and remove guide rail.



Installation

- 7 Coat bearing bolt on collar with sealing compound.


- 8 Insert slide rail and knock in bearing bolt with impact puller.

Apply counterhold to slide rail with screwdriver.

- 9 Mount camshaft timing gear. Pay attention to color marks.


For assembly of camshaft timing gear, push back thrust bolt of chain tensioner.

Tighten fastening screw for camshaft timing gear to 45 Nm. For this purpose, apply counterhold to camshaft with a screwdriver or a mandrel.



- 10 Set engine to ignition TDC of 1st cylinder and check mark (arrows).

- 11 Mount cylinder head cover.




B. Removal and installation of guide rail (218)

1 Remove timing housing cover (01–210).

2 Pull out slide rail (218).

3 For installation proceed vice versa.



14 OH nozzle
18 Injection timer
215 Tensioning rail



218 Slide rail
262 Tensioning clamp

105-25817

05-437 Removal and installation of drive for hydraulic oil pump


Tightening torques	Nm
Cylinder head cover	10
Hex. socket screw for camshaft timing gear	45
Hydraulic oil pump (level control) on fastening flange	15

Special tools

Torque wrench, double arm, 3/8" square, 8-32 Nm		001 589 51 21 00
Torque wrench with plug-in ratchet, 1/2" square, 25-30 Nm		001 589 66 21 00


Note

70	Cylinder head	401	Cyl. pin
81	Camshaft bearing cap	402	Flange
84	Combination screw M 8 x 45	403	Driven plate
125	Cylinder head cover	404	O-ring
129	Cylinder head cover gasket	405	Hex. socket screw
185	Camshaft	406	Drive sleeve
186	Lockwasher	407	Hex. socket screw
188	Camshaft timing gear		
400	Hydraulic oil pump		



The hydraulic oil pump (400) is directly driven by camshaft (185) via drive sleeve (406) and is fastened to cylinder head by means of a flange (402).

The installation position of flange on cylinder head is fixed by means of two cyl. pins (arrows).



The camshaft timing gear (188) is fastened to camshaft together with drive sleeve (406) by means of a hex. socket screw (405).


The O-ring on flange (402) seals the half bore at front on cylinder head and in cylinder head cover.

Removal

Remove cylinder head cover.

2 Unscrew hex. socket screws (arrows) and put hydraulic oil pump aside with lines connected.

Remove driven plate.



3 Unscrew hex. socket screw (405) for camshaft timing gear and drive sleeve and remove.

For loosening hex. socket screw, apply counterhold to camshaft with holding wrench.

Installation

4 For installation proceed vice versa to removal.

Tighten hex. socket screw for camshaft timing gear and drive sleeve to 45 Nm. For this purpose, apply counterhold with a screwdriver or a mandrel.

