




Check Regularly and Before a Long Trip



1 Fuel Supply: Turn fuel filler cap to the left and hold on to it until possible pressure in tank has been released, then remove the cap.

2 Tire Inflation Pressure: Check at least every two weeks. For details see page 84.

3 Windshield Washer System and Headlamp Cleaning System: See page 113.

4 Coolant Level: See page 76.

5 Engine Oil Level: See page 77.

6 Brake Fluid: See pages 112 and 114.

Vehicle Lighting: Check function and cleanliness. For replacement of light bulbs, see pages 85, 86 and 87.