

MERCEDES-BENZ Maintenance System

A maintenance booklet is included with your car, listing all the maintenance jobs that must be carried out after the following mileages:

Routine Maintenance

Inspection at
1300 –1600 km (800 –1000 miles)

Lubrication Service every
12 000 km (7500 miles)

Maintenance Service every
24 000 km (15 000 miles)

Additional Work every
48 000 km (30 000 miles)

For additional details refer to the
Maintenance Booklet.

In the case of low mileage
operation, the Maintenance
Service must be carried out at
least once every 2 years.

Engine Oil and Filter Change

Required every 12 000 km
(7500 miles), or at least once a
year.

For engine oil recommendations,
see page 111.

Severe Operating Conditions

Under severe operating conditions or heavy use, it may be necessary to carry out prescribed maintenance jobs at shorter intervals, for example:

Engine: Oil change with filter
change every 6000 km
(3750 miles)

Automatic transmission: Fluid
change without filter change every
24 000 km (15 000 miles)

Tires: Inspect every 12 000 km
(7500 miles)

Air filter: Clean or replace element
every 24 000 km (15 000 miles)

Note:

Severe operating conditions or
heavy use include: predominant
city or short distance driving, fre-
quent mountain driving, poor
roads, dusty or muddy conditions,
etc..

Special Maintenance Measures

Brake fluid should be replaced
annually, preferably in the spring.

It is recommended to use only
brake fluid approved by
MERCEDES-BENZ. Do not mix
different types of brake fluids.

Have the engine coolant
(water/anticorrosion/antifreeze
mixture) replaced every three
years (see "Fuels, Coolants,
Lubricants, etc.").

Maintenance Vouchers

Your authorized MERCEDES-
BENZ dealer will certify in the
maintenance booklet that all
lubrication and maintenance
services have been carried out at
the correct intervals.