

### First Aid Kit

The first aid kit is stored in the shelf below the rear window. To open the lid, push button (1).


## Stowing Things in the Vehicle

### Warning!

To help avoid personal injury during a collision or sudden maneuver, exercise care when stowing things. Put luggage or cargo in the trunk if possible. Do not pile luggage or cargo higher than the seat backs. Do not place anything on the shelf below the rear window.

### Vehicle Tools

The vehicle tools are located in the spare wheel well.



### Spare Wheel

1 Trunk floor

2 Strap

3 Luggage bowl

Roll back the floor mat, lift the trunk floor (1) and engage strap (2) in the trunk lid.

To remove the spare tire, turn luggage bowl (3) to the left and remove.